

**Magnum VS 50  
Magnum VS 100  
-48 Vdc Power Systems  
User's Manual**



# Table of Contents

1	Safety First!	1
1.1.	WARNING SYMBOLS	1
1.2.	GENERAL PRECAUTIONS:	1
2	Introduction	2
2.1.	GENERAL INFORMATION	2
2.2.	HOW TO USE THIS MANUAL	2
3	Installation	4
3.1.	UNPACKING EQUIPMENT	4
3.2.	MECHANICAL INSTALLATION	4
	<i>Room / Location</i>	4
	<i>Mounting</i>	4
	<i>Ventilation</i>	5
3.3.	AC POWER CONNECTIONS	5
	<i>AC Connections</i>	5
	<i>AC Power Cord Sets</i>	6
3.4.	BATTERY CONNECTIONS	7
	<i>Planning the Battery installation</i>	7
	<i>Connecting the Cables</i>	7
	<i>Battery Temperature Probe Installation</i>	8
3.5.	COUNTER ELECTRO-MOTIVE FORCE (CEMF) CELL CONNECTIONS	9
3.6.	DC SYSTEM GROUNDING	9
3.7.	LOAD PROTECTION INSTALLATION	10
	<i>Circuit Breaker Installation</i>	10
	<i>GMT Fuse Installation</i>	10
3.8.	LOAD CONNECTIONS	11
	<i>Cable Size Considerations</i>	11
	<i>Circuit Breaker Protected Load Connections (30 or 60 A)</i>	11
	<i>GMT Fuse protected Load Connections</i>	11
3.9.	MONITORING AND RELAY OUTPUT CONNECTIONS	12
	<i>Front Panel DB9 Connection</i>	12
	<i>RJ45 Ethernet Connector</i>	12
	<i>Major, Minor and Relay 1 Output Connections</i>	12
	<i>Output Relay 2-6 Connections</i>	13
	<i>External Alarm Input Connections</i>	14
3.10.	RECTIFIER MODULE INSTALLATION	14
3.11.	CONTROLLER MODULE INSTALLATION	15
4	Commissioning	16
4.1.	PRE-COMMISSIONING INSPECTION	16
	<i>Environment</i>	16
	<i>Electrical Installation</i>	16
	<i>Battery Visual and Safety Inspection</i>	16
4.2.	COMMISSIONING	17
	<i>Initial Set-up</i>	17

AC Power Up.....	17
DC Power Up:.....	17
Rectifier Test:.....	18
Battery Power Up.....	18
LVD Test.....	18
Circuit Breaker/ Fuse Test:.....	18
User Inputs .....	18
Output Relay 1:.....	19
Battery Temperature Compensation.....	19
4.3. FINAL INSPECTION:.....	19
5 Technical Description .....	20
5.1. RECTIFIER MANAGEMENT.....	20
AC Input Power.....	20
DC Output Power.....	20
Rectifier alarms reporting.....	20
5.2. SYSTEM MANAGEMENT .....	20
System Voltage Monitor and Control .....	20
System Current Monitor.....	21
System Status and Alarm Reporting.....	21
5.3. LOAD MANAGEMENT .....	21
Circuit Breakers .....	21
GMT Fuses.....	22
5.4. BATTERY MANAGEMENT .....	22
Battery Charging.....	22
Battery Equalization.....	23
Battery Protection .....	23
Battery Temperature Monitoring .....	23
Battery Temperature Compensation.....	23
Battery Low Voltage Disconnect.....	24
Battery Functional Test.....	24
Counter Electro-Motive Force Module Connections .....	24
5.5. CONTROLS AND INDICATORS .....	25
Controller with Display .....	25
Controller without Display.....	25
5.6. ALARM OUTPUTS (OUTPUT RELAYS).....	25
5.7. EXTERNAL ALARM INPUTS (USER INPUT).....	26
5.8. NETWORK MANAGEMENT CARD - LOCAL & REMOTE MONITORING .....	26
6 Operation.....	27
6.1. DESCRIPTION.....	27
6.2. CONTROLLER CARD JUMPERS.....	27
System voltage J5 .....	27
Remote Lockout J8.....	27
Firmware Programming Enable J9 .....	27
Vtrim Trip Select J13 .....	27
6.3. CONTROLLER WITH DISPLAY.....	28
6.4. OPERATION USING LOCAL DISPLAY AND KEYPAD INTERFACE .....	29

6.5.	CONTROLLER WITHOUT DISPLAY.....	36
6.6.	OPERATION USING THE RS-232 COMM PORT .....	36
6.7.	OPERATION USING THE 10/100 BASET ETHERNET PORT .....	37
6.8.	OPERATION USING NETWORK MANAGEMENT CARD WEB BROWSER INTERFACE .....	37
6.9.	LVD OPERATION .....	44
6.10.	PROGRAMMING OUTPUT RELAYS.....	45
7	Preventive Maintenance .....	47
7.1.	EQUIPMENT .....	47
7.2.	INSPECTION .....	47
	<i>Environmental Inspection .....</i>	<i>47</i>
	<i>System Visual and Safety Inspection.....</i>	<i>47</i>
	<i>Battery Visual and Safety Inspection .....</i>	<i>48</i>
7.3.	TEST .....	48
	<i>System Voltage Test.....</i>	<i>48</i>
	<i>Rectifier Current Share Test .....</i>	<i>48</i>
	<i>System Current Test.....</i>	<i>48</i>
	<i>Rectifier Alarm Test .....</i>	<i>48</i>
	<i>System Temperature Test .....</i>	<i>49</i>
	<i>Battery Current Test .....</i>	<i>49</i>
	<i>Battery Temperature Test.....</i>	<i>49</i>
	<i>LVD Test.....</i>	<i>49</i>
	<i>Battery Preventive Maintenance Procedure .....</i>	<i>50</i>
7.4.	FINAL INSPECTION: .....	50
8	Alarm Summary .....	51
9	Specifications.....	53
9.1.	AC INPUT .....	53
	<i>TWF0500H54B Rectifier.....</i>	<i>53</i>
	<i>Magnum VS 50 Power System.....</i>	<i>53</i>
	<i>Magnum VS 100 Power System .....</i>	<i>54</i>
9.2.	DC OUTPUT .....	54
	<i>TWF0500H54B Rectifier.....</i>	<i>54</i>
	<i>Magnum VS 50 Power System .....</i>	<i>55</i>
	<i>Magnum VS 100 Power System .....</i>	<i>55</i>
9.3.	CONTROLS AND INDICATORS .....	56
	<i>TWF0500H54B Rectifier.....</i>	<i>56</i>
	<i>Magnum VS Controller .....</i>	<i>56</i>
9.4.	MECHANICAL .....	56
	<i>TWF0500H54B Rectifier.....</i>	<i>56</i>
	<i>Magnum VS 50 Power System .....</i>	<i>56</i>
	<i>Magnum VS 100 Power System .....</i>	<i>57</i>
9.5.	ENVIRONMENTAL .....	57
9.6.	COMPLIANCE .....	58
10	APC Worldwide Customer Support.....	59
11	Limited Product Warranty .....	60

## Revision History

Document # & Rev	Date	By	Description
990-1479	06 MAY, 2003	BET	Initial Release
990-1479A	03 JUL, 2003	BET	Clean-up after Pilot Run
990-1479B	30 SEP, 2003	BET	Add Controller with Display
990-1479C	28 OCT, 2003	BET	Correct dc connections
990-1479D	06 JAN, 2004	BET	Added Output Relays 2-6

## Table of Figures


FIGURE 2.1-1 MAGNUM VS 50 –48 VDC POWER PLANT .....	2
FIGURE 2.2-1 MAGNUM VS BLOCK DIAGRAM.....	3
FIGURE 3.3-1 MAGNUM VS 50 BACKPLANE .....	5
FIGURE 3.3-3 AC INPUT WIRING.....	6
FIGURE 3.3-5 POWER CORD SETS .....	6
FIGURE 3.4-1 BATTERY CABLE CONNECTION LOCATIONS.....	8
FIGURE 3.4-3 BATTERY TEMPERATURE PROBE INSTALLATION .....	8
FIGURE 3.5-1 CEMF CONNECTION LOCATIONS .....	9
FIGURE 3.7-1 GMT FUSE TEMPERATURE DE-RATING CHART .....	10
FIGURE 3.7-3 GMT FUSES AVAILABLE FROM APC .....	10
FIGURE 3.8-1 CONNECTIONS TO CIRCUIT BREAKERS.....	11
FIGURE 3.8-2 TOP SHELF GMT FUSE CONNECTIONS .....	12
FIGURE 3.8-3 BOTTOM SHELF GMT FUSE CONNECTIONS .....	12
FIGURE 3.9-1 INTERFACE CONNECTIONS.....	13
FIGURE 3.9-3 OUTPUT RELAY CONNECTIONS.....	14
FIGURE 3.9-5 EXTERNAL USER INPUT CONNECTIONS.....	14
FIGURE 6.2-1 CONTROLLER CARD JUMPER LOCATIONS .....	28
FIGURE 6.3-1 CONTROLLER WITH DISPLAY .....	29
FIGURE 6.4-1 PARAMETER LOCATIONS, DESCRIPTIONS, AND DEFAULT VALUES .....	30
FIGURE 6.4-2 MAGNUM VS ENGLISH DISPLAY TREE .....	34
FIGURE 6.4-3 MAGNUM VS CHINESE DISPLAY TREE .....	35
FIGURE 6.5-1 MAGNUM VS CONTROLLER WITHOUT DISPLAY .....	36
FIGURE 6.8-1 PARAMETER LOCATIONS, DESCRIPTIONS, AND SETTINGS .....	38


Entire contents copyright © 2003 American Power Conversion. All rights reserved.  
Reproduction in whole or in part without permission is prohibited. APC and the APC logo are  
trademarks or registered trademarks of American Power Conversion Corporation. All other  
trademarks, product names, and corporate names are the property of their respective owners  
and are used for informational purposes only.

# 1 **Safety First!**


It is very important to follow all safety procedures when unpacking, installing and operating any sort of power equipment.


## 1.1. Warning Symbols


	<b>CAUTION:</b> An indication that special care is required to prevent injury, equipment damage or misuse.
---	--

	<b>WARNING:</b> An indication of an electrical hazard that may cause serious personal injury or death, catastrophic equipment damage or site destruction.
---	---

## 1.2. General Precautions:

	<b>WARNING:</b> Hazardous ac voltage levels are present inside the power system. Keep the rear cover in place when the system is operational or energized.
--	--

	<b>WARNING:</b> Hazardous energy levels are present on bare conductors in the distribution connection area of the plant. Accidental shorting of distribution conductors can cause arcing and high currents that can cause serious burns or other physical harm. It is recommended that: <ul style="list-style-type: none"><li>• Remove any jewelry, rings or watches while working on this equipment.</li><li>• Use insulated wrenches, screwdrivers, cutters, pliers and other tools.</li></ul>
---	--

	<b>WARNING:</b> Ensure that all of the dc and external ac circuit breakers are in the OFF position prior to connecting service to the power plant. Confirm that all voltages have been removed including any battery sources before proceeding.
---	---

Specific **CAUTION** and **WARNING** will be placed in manual where appropriate.

### 2.1. General Information

DC Power Plants from APC have unique features that make them easy to install, maintain, and upgrade. The rectifier units are modular and truly “hot-pluggable” into the shelf assembly without any separate ac wiring. The Magnum VS 50 has 1 shelf, holding up to five rectifiers for a rated current of 50 A. The Magnum VS 100 has 2 shelves, holding up to ten rectifiers for a rated current of 100 A. All system settings are made from a standard PC using a serial cable or a 10/100 Base T connection. The controller provides monitoring and control functions for each component of the system and stores alarm listings for system diagnosis and maintenance. For ease of operation, a display with LCD readout and 5-button keypad can be inserted in rectifier slot 5




Figure 2.1-1 Magnum VS 50 –48 Vdc Power Plant

The APC Magnum VS is a modular stand-alone -48 Vdc power plant. It is configurable in such a manner that it will support most typical applications within the specified current ranges (10-100 A) without special application engineering or assistance. DC output distribution is included for circuit breakers or GMT style fuses or in the 100-A versions, a combination of both. Available circuit breakers are 30 A or 60 A. GMT fuses can be 1/4 to 15 A. A low voltage disconnect (LVD) is provided to disconnect the battery after deep discharge. A 50-ampere power system is shown in Figure 2.1-1. A block diagram of a typical 100-ampere power system with fuses and breakers is shown in Figure 2.2-1.

### 2.2. How to Use This Manual

Each section of this manual can be read in any order and provides a complete explanation of the subject described by the title. However, the sequence of the sections is designed to provide a typical step-by-step process for successful use of the equipment.




Figure 2.2-1 Magnum VS BLOCK DIAGRAM



### 3.1. Unpacking Equipment

Remove equipment from packing material and inspect for shipping damage or missing items. It is important to report damage or material shortages to the shipping carrier while a representative is on site.

If concealed damage or material shortages are found at a later time, contact the shipper to make arrangements for inspection and claim filing. Refer to **Section 10** in the event it is necessary to return equipment to APC.



**CAUTION:** Appropriate lifting techniques and safety equipment should be used to remove equipment from packing.



**PLEASE RECYCLE:** The shipping materials can be recycled. Please save them for later use or dispose accordingly.

### 3.2. Mechanical Installation

#### Room / Location

**NOTE:** The APC dc power plant is to be installed in a room, vault, or similar enclosure that is accessible only to qualified persons in accordance with the regulatory authority having jurisdiction.

Prior to installation, drawings, floor loading requirements, external alarm points, ac service entrance, and grounding schemes should all be checked and confirmed. If batteries are to be mounted in a room separate from the power plant, careful attention should be paid to battery cable voltage drop effects. Environmental operating temperatures and ventilation/cooling considerations should also be noted, not just for the power system but also for all other equipment that may reside in the power room area.

#### Mounting

The Magnum VS provides brackets to mount on a standard EIA 19 or 23-inch rack. Install the power system using hardware designed for the rack. To install a Magnum VS 50 on a 23-inch rack use bracket kit number 0M-2829. To install a Magnum VS 100 on a 23-inch rack use bracket kit number 0M-2830.

## Ventilation

The rectifier modules for this system have fans that provide front-to-rear airflow for internal cooling. The power system housing should be mounted such that there is free airflow to the front and back of the unit. [Refer to **Section 9.5** for environmental characteristics.] Free airflow should be ensured so that the power system can provide full power without de-rating.

## 3.3. AC Power Connections



**WARNING:** Ensure that all of the external dc and ac circuit breakers are in the OFF position prior to connecting service to the power plant. Confirm that all voltages have been removed including any battery sources before proceeding.

### AC Connections

The dc power system requires the supply of 85 – 264 Vac, 47 – 63 Hz single phase power. One alternating current (ac) input on the power system backplane supplies power to the first rectifier in each shelf. Two inputs supply power to the second and third pair of rectifiers and the fourth and fifth pair in each shelf. This scheme allows a variety of wiring options. Provided the input wiring is not overloaded, one, two or all three inputs on each shelf can be jumpered together. The ambient temperature and number of wires in a conduit must be considered in accordance with NEC and local requirements. The power system typically ships with the jumpers shown in the backplane layout of the Magnum VS 50 shown in Figure 3.3-1. The Magnum VS 100 contains two identical backplanes. The input terminals are defined in Figure 3.3-3. If one ac input cable is used it is typically connected to TRM10, 7 and 4.




Figure 3.3-1 Magnum VS 50 Backplane

Rectifier	Terminal #	Function	Terminal #	Function	Terminal #	Function
Rectifier 1	TRM2	Ground	TRM5	Line or Neutral	TRM8	Line
Rectifier 2 & 3	TRM3	Ground	TRM6	Line or Neutral	TRM9	Line
Rectifier 4 & 5	TRM4	Ground	TRM7	Line or Neutral	TRM10	Line
Chassis	TRM1	Ground				

Figure 3.3-3 AC Input Wiring

## AC Power Cord Sets

AC input cable kits are available from APC. These cables are 12 feet (3.7m) long and have a power plug installed on each cable. When ordered with the power system, these cables will be installed with strain reliefs provided to mount the 3-conductor jacketed cables. Each kit will supply power to the entire power system. Use the chart in Figure 3.3-5 to determine the suggested cable kits.

Part Num.	AWG	Cable Qty	Plug Num.	Plug Style	Voltage	Power System
0M-91157	14	3	NEMA 5-15	Non-locking	115	Magnum VS 50
0M-91155	14	3	NEMA L5-15	Locking	115	Magnum VS 50
0M-91156	12	2	NEMA 5-20P	Non-locking	115	Magnum VS 50
0M-91154	12	2	NEMA L5-20P	Locking	115	Magnum VS 50
0M-91158	10	1	NEMA 5-50P	Non-locking	115	Magnum VS 50
0M-1150	12	2	NEMA L6-20P	Locking	230	Magnum VS 50
0M-91160	10	1	NEMA 6-30P	Non-locking	230	Magnum VS 50
0M-91159	10	1	NEMA L6-30P	Locking	230	Magnum VS 50
0M-91137	12	6	NEMA 5-15P	Non-Locking	115	Magnum VS 100
0M-91140	12	6	NEMA L5-15P	Locking	115	Magnum VS 100
0M-91138	12	4	NEMA 5-20P	Non-locking	115	Magnum VS 100
0M-91141	12	4	NEMA L5-20P	Locking	115	Magnum VS 100
0M-91139	10	2	NEMA 5-50P	Non-locking	115	Magnum VS 100
0M-1149	12	4	NEMA L6-20P	Locking	230	Magnum VS 100
0M-91135	10	2	NEMA 6-30P	Non-locking	230	Magnum VS 100
0M-91136	10	2	NEMA L6-30P	Locking	230	Magnum VS 100

Figure 3.3-5 Power Cord Sets



**WARNING:** Hazardous ac voltage levels are present inside the power system. Keep the rear cover in place when the system is operational or energized.

The rear cover of each shelf in the power system is provided with two 1.125-inch (2.858 cm) diameter holes for electrical conduit. Conduit can be run to each shelf or strain reliefs are provided to install jacketed cables.

### 3.4. Battery Connections



**WARNING:** Hazardous energy levels are present on bare conductors in the dc distribution connection area of the plant. Accidental shorting of distribution conductors can cause arcing and high currents that can cause serious burns or other physical harm. It is recommended that:

- Remove any jewelry, rings or watches while working on this equipment.
- Use insulated wrenches, screwdrivers, cutters, pliers and other tools.

#### Planning the Battery installation


The battery cable(s) should be sized to limit the voltage drop from the dc power plant to the battery during charging per system design requirements. The cable(s) must also carry the full load current during battery operation. If assistance is required to determine the necessary cables for the application, contact your sales representative or APC (Refer to Section 10 for APC Customer Support information. A fuse or circuit breaker (various options are available from APC) is recommended in the negative line to protect the cables from the battery to the dc power plant. If a circuit breaker is used, the power plant can monitor auxiliary contacts from this breaker.

#### Connecting the Cables



**WARNING:** Make certain that the battery polarity is correct when making connections to the dc power plant. Incorrect connection could cause severe equipment damage.

The battery cable connections are located at the rear of the unit as shown in Figure 3.4-1. The battery positive and battery negative buses each provide a pair of #10-32 studs on 5/8" centers for connecting two-hole battery cable lugs. A ring size of 6 mm may also be used. Connect the battery cables as applicable using #10-32 nuts. Cover connections with heat shrink after assembly.





**Figure 3.4-1 Battery Cable Connection Locations**

### Battery Temperature Probe Installation

The temperature probe is used to monitor the battery string temperature. To get the most representative temperature measurement, the probe should be placed in contact with a battery cell that is centrally located. The probe should be placed directly in contact with the cell (not the frame surrounding the cell). Generally, the cell cover can be used; be careful not to allow the probe body to touch the terminals. Plug the connector end of the temperature probe into J410 of the backplane card. Route the cable as required positioning the probe on the selected battery cell. Remove the adhesive protection strip from the probe body and press the adhesive side of the probe on the battery cell cover. Refer to Figure 3.4-3 for details.

**Note:** Program Hardware battery temperature alarm to ignore if no battery temperature probe is connected to J410.



**Figure 3.4-3 Battery Temperature Probe Installation**

### 3.5. Counter Electro-Motive Force (CEMF) Cell Connections



**WARNING:** Hazardous energy levels are present on the CEMF connection area of the plant. Accidental shorting of conductors can cause arcing and high currents that can cause serious burns or other physical harm.

In some applications, a CEMF cell is used to lower the dc voltage delivered to the loads. The CEMF cell is mounted externally to the Magnum VS. The CEMF connections are located at the rear of the unit as shown in Figure 3.5-1. Two bus-plates, installed at the factory, bypass the CEMF connection. If a CEMF cell will be used, remove the bus plate connecting the two CEMF connection points and install two connection buses before installing the CEMF. The CEMF connection buses each provide a pair of #10-32 studs on 5/8" centers for connecting two-hole CEMF cable lugs. A ring size of 6 mm may also be used. Connect the CEMF cables as applicable using #10-32 nuts.




Figure 3.5-1 CEMF Connection Locations

### 3.6. DC System Grounding

The positive bus for the power plant should be connected to the Central Office Ground. The Battery Return provide a pair of #10-32 studs on 5/8-inch centers for connection of a two-hole lugged cable to the Central Office Ground. A ring size of 6 mm may also be used. Cover this connection with heat shrink tubing after assembly.

## 3.7. Load Protection Installation

### Circuit Breaker Installation

Standard circuit breaker output boards are available with two 30-A breakers or one 60-A breaker. Output boards are installed at the factory and are generally not field replaceable units. Contact APC if the output configuration is not suitable for your needs. Other breaker sizes are not readily available.

### GMT Fuse Installation

Fuse holders that accommodate GMT fuses are located on the front panel on the left side of the unit. Insert the fuse in the holder; observing the tripped indicator is correctly oriented. Use the chart shown in **Figure 3.7-1** to help determine what size fuses will carry the desired current. When using several of the larger GMT fuses in one shelf, better heat dissipation will be achieved if the fuses are spaced out evenly within the output panel. A list of GMT type fuses available from APC is provided in Figure 3.7-3.

		AMBIENT TEMPERATURE		
		20° C	50° C	60° C
FUSE SIZE	7.5 A	5 A	4.5 A	4 A
	10 A	7 A	6 A	5 A
	15 A	10 A	9 A	8 A

Figure 3.7-1 GMT Fuse Temperature De-rating Chart

GMT Fuses				
FUSE RATING	PART NUMBER		FUSE RATING	PART NUMBER
¼ A	FFA-0030		3 A	FFA-0036
½ A	FFA-0031		5 A	FFA-0037
¾ A	FFA-0032		7½ A	FFA-0029
1 A	FFA-0033		10 A	FFA-0038
1¼ A	FFA-0039		15 A	FFA-0040
1½ A	FFA-0035			

Figure 3.7-3 GMT fuses available from APC

## 3.8. Load Connections

### Cable Size Considerations

The dc load cable(s) should be sized to limit the voltage drop from the dc power plant to the loads per system design requirements. The cable(s) must also carry the full load current during battery operation. During battery operation the voltage will be lower and for constant power loads, the current will typically be higher. If assistance is required to determine the necessary cables for the application, contact your sales representative or APC.

### Circuit Breaker Protected Load Connections (30 or 60 A)

The circuit breaker lug landing connection provides a pair of #10-32 studs on 5/8" centers for mounting two-hole lugs. A ring size of 6 mm may also be used. A right angle bus bar with two studs is provided to land the lugs. Load Connections should be made as shown in. Cover connections with heat shrink after assembly.





Figure 3.8-1 Connections to Circuit Breakers


### GMT Fuse protected Load Connections

Connections for 1/4 to 14-A loads require a ring terminal with a 0.170 in (4.3 mm) clearance hole and are located at the rear of the unit. Load connections should be made as shown in Figure 3.8-2 and Figure 3.8-3





**Figure 3.8-2 Top Shelf GMT Fuse Connections**



**Figure 3.8-3 Bottom Shelf GMT Fuse Connections**

## 3.9. Monitoring and Relay Output Connections

### Front Panel DB9 Connection

The front panel DB-9 connector is used to hook up a standard RS-232 cable (such as APC part number 0129-XX. A 0129-6 is included with this manual. ). This will allow local access through a Terminal Emulation program such as HyperTerminal™ or Procomm.™

### RJ45 Ethernet Connector

The management card has an RJ-45 connector to support a TCP/IP protocol over a 10/100 BaseT Ethernet Local Area Network (LAN).

### Major, Minor and Relay 1 Output Connections

There are three output relays available that provide outputs via Form “C” contacts. The output relays are named Minor, Major and Out Relay 1. Various system alarm conditions can be assigned to any of these three output relays. Most alarm conditions are shipped programmed to Minor or Major Relay. Wago connectors are located on the backplane card mounted in the left rear of the unit. Refer to the board layout in Figure 3.9-1 for Output Relay connections. The Wago connectors accept wires 26 AWG to 20 AWG (0.129mm<sup>2</sup> to 0.518 mm<sup>2</sup>). To connect the relay output, remove ¼ in (6mm) of insulation from the end of the wire. Push down the white tab on the Wago connector, insert the stripped wire and release the tab to make the connection. The relay contacts should only be used to switch resistive loads of 0.5 A or less at 60 V or less.

Figure 3.9-3 shows the alarm output connection designations. Whenever possible use the common and normally closed contacts. If the alarm wiring gets pulled loose, or the controller is removed, you will get an alarm. The Major relay is energized (C-NO contacts closed) during normal (non-alarm) operating conditions; the other relays energize when an alarm condition occurs. If your Major relay wiring uses the C-NO contacts, then a major relay output will be seen whenever the controller is removed from the shelf.




Figure 3.9-1 Interface Connections

Output Relay 2-6 Connections

Output Relays 2 through 6 are virtual relays and are not available for physical connection by the user. The small size of this unit limits the number of relays that can be placed in the system. These output relays are supported by the controller and reported by the network management card. Any alarm condition can be programmed to map to one of these relays. The alarm will activate the relay, illuminate the front panel Out Relay LED, and send the relay output message to the network management card.

RELAY OUTPUT	J 411 TERMINAL DESIGNATIONS	RELAY ALIAS	OUTPUT RELAY NOTES
OUT RELAY #1	NO		
	C		
	NC		
OUT RELAY #2	N/A		
OUT RELAY #3	N/A		
OUT RELAY #4	N/A		
OUT RELAY #5	N/A		

OUT RELAY #6	N/A		
MINOR	NO	N/A	
	C	N/A	
	NC	N/A	
MAJOR	NO	N/A	
	C	N/A	
	NC	N/A	

Figure 3.9-3 Output Relay Connections

## External Alarm Input Connections

Four external alarm inputs with assignable relay outputs are available. User 1 and 2 inputs respond only to external dry contact closures between normally open (NO) and common (C) and User 3 and 4 respond only to external dry contact openings between normally closed (NC) and C. A Wago connector is located on the backplane card mounted in the left rear of the unit. The Wago connectors accept wires 26 AWG to 20 AWG (0.129mm<sup>2</sup> to 0.518 mm<sup>2</sup>). To connect the user input, remove ¼ in (6mm) of insulation from the end of the wire. Push down the white tab on the Wago connector, insert the stripped wire and release the tab to make the connection. Refer to **Figure 3.9-1** for backplane board connections.

EXTERNAL ALARM INPUT	J412 TERMINAL DESIGNATIONS	USER ALARM NOTES
#1 NO	USER1NO	
#2 NO	USER2NO	
#3 NC	USER3NC	
#4 NC	USER4NC	
#1 C	USER1C	
#2 C	USER2C	
#3 C	USER3C	
#4 C	USER4C	

Figure 3.9-5 External User Input Connections

## 3.10.Rectifier Module Installation



**WARNING:** Rectifier dc output circuits will be damaged if battery is installed incorrectly. Before rectifier installation, ensure proper battery polarity and that the battery is isolated from the rest of the system

The rectifier modules are shipped in separate containers. Follow the procedure below to install a rectifier module. Rectifiers may be installed even when the system is energized.

- 1) Remove the rectifier from its shipping container.

- 2) Slide the rectifier module into the shelf between the guides until it is fully seated.
- 3) Fasten the rectifier in place with the captive rectifier retaining screws.

Since all adjustments are made from the system controller, no rectifier adjustments are necessary.

### 3.11. Controller Module Installation



**CAUTION:** The controller and the network management card have lithium batteries. These batteries are not field serviceable.

- Danger of explosion if battery is replaced by an incorrect type.
- Dispose of used batteries according to the manufacturer's instructions.

The controller is installed in the Magnum VS 50 in the right hand side of the power system. The controller is installed in the Magnum VS 100 in the upper right hand side of the power system. Insert the card taking care to follow the alignment guides all the way to the rear of the unit. The connector on the rear will hot plug into the power system backplane.

To install the controller with display, first remove rectifier number 5, which is in the slot nearest the controller. Insert the card taking care to follow the alignment guides all the way to the rear of the unit. The connector on the rear will hot plug into the power system backplane. Removing the rectifier will decrease the total output capacity of the power system.

## **4      *Commissioning***

---

This section is intended as a guide when powering up a system for the first time. It may not be desirable to perform some steps depending on the particular installation. Refer to the appropriate section for information relating to how these steps should be performed.

### **4.1. Pre-Commissioning Inspection**

#### **Environment**

1. Ensure the dc system environment is suitable for operation.
2. Ensure that there is sufficient clearance around the system for service.
3. Ensure that there is no sign of damage to the dc system.
4. Disable installed alarms before servicing the unit. This will allow the unit to be serviced without creating false alarms.

#### **Electrical Installation**

1. Ensure that the dc wiring is properly installed, sized, terminated and identified.
2. Ensure that the ac wiring is properly installed, sized, terminated and identified.
3. Ensure that the battery wiring is properly installed.
4. Ensure that the dc output over-current protection devices are adequate for the size of wiring installed.
5. Ensure that the dc positive is bonded to central office ground.
6. Note the resistance of the ground bond.
7. Note any currents flowing in the ground.
8. Record ambient temperature.
9. Verify that the battery polarity is correct.
10. If a battery disconnect device(s) is/are present, note the following for each device:
  - a. DC voltage Rating.
  - b. DC Current Rating
  - c. Interrupting Current Rating

#### **Battery Visual and Safety Inspection**

1. Check the mechanical integrity of the battery framing, racking, or cabinet.
2. Check that the battery framing, racking or cabinet is adequately secured to the floor.
3. Check compliance with seismic zone requirements.
4. Check the general appearance and cleanliness of the battery.
5. Record the manufacturer, model number, and capacity of the battery string(s).
6. Record the batch number, date code, and serial number of each cell or mono-block, and any other pertinent information that is available on the battery cells.
7. Check that the cell or mono-block numbering starts at the positive battery string terminal and is correct.

8. Check that anti-oxidation compound is properly applied.
9. Visually inspect each cell for:
  - a. Cracks.
  - b. Case leaks.
  - c. Post-seal leaks.
  - d. Pressure relief valve leaks (VRLA only).
  - e. Case swelling (VRLA only).
10. Check the torque of all battery inter- cell connector in accordance with the battery manufacturer's specifications.

## 4.2. Commissioning

### Initial Set-up

1. Remove all rectifiers.
2. Disconnect battery by removing a link in each string or opening the battery disconnects.
3. Check that battery voltage does not appear on the system bus.
4. Disconnect all loads.

### AC Power Up



**WARNING:** The dc power plant is supplied from a nominal high voltage ac voltage source. Keep the ac input enclosure cover in place when the system is operational or energized

1. Verify that all of the circuit breaker positions are labeled to the corresponding rectifier correctly.
2. Insert all rectifiers.
3. Turn all rectifier circuit breakers on.
4. Each rectifier should have green Input Healthy and Output Healthy LEDs illuminated.

**NOTE:** When ac power is initially applied, there is a 60-second period during which no alarms are reported.

### DC Power Up:

1. Verify with a voltmeter that the dc voltage is within 0.1 Vdc of the System Voltage
2. Adjust battery float voltage to negative 49 Vdc.
3. Verify System Low Voltage Alarm.
4. Adjust battery float voltage to negative 57 Vdc.
5. Verify System High Voltage Alarm.
6. Restore the battery float voltage to negative 54.00 Vdc or desired voltage.

### **Rectifier Test:**

1. To verify that all rectifiers are reporting correctly to the controller, navigate through the menu and verify that the status for every rectifier in the system is correct.
2. Remove any rectifier and verify that you get a Minor Relay Output for rectifier 1 of n failure.
3. Remove a second rectifier and verify that you get a Major Relay Output for rectifier 2 of n failure.

### **Battery Power Up**

1. Monitor battery current and verify that it is +/- 0.1 A.
2. Set battery maximum recharge value in the Max Batt Rech screen.
3. Monitor the battery current while closing the battery disconnects or installing open battery links. Arcing can occur during this connection.
4. The voltage may drop if the maximum battery recharge current is exceeded.
5. The current should gradually decrease when the battery is nearing full charge.

### **LVD Test**

1. Enable LVD 1.
2. Set the LVD trip for LVD 1 to negative 56 Vdc.
3. The LVD should have dropped out (opened). Verify by monitoring the voltage at the battery connection. Also, the minor alarm should be on.
4. Set LVD Trip back to negative 42 Vdc.
5. The LVD should have closed. Verify visually or by monitoring the voltage at the battery connection. The minor alarm should be off.
6. Ensure that the LVD parameters are set to desired value.

### **Circuit Breaker/ Fuse Test:**

1. Monitor alarm screen for fuse alarm while installing blown GMT fuses in each position.
2. Verify proper voltage at fuse and circuit breaker output connections.
3. Turn on fuses and circuit breakers as desired.

### **User Inputs**

1. Change the user input to desired output relay via the controller for any input that will be used.
2. Exercise the output relay by causing the user input to change state.
3. Verify the desired relay output LED on the controller module.

### **Output Relay 1:**

1. Minor and Major output relays were tested in the rectifier test section.
2. Change the alarm to desired relay output via the controller for any relay output that will be used. All alarm parameters are shipped as either major or minor, but may be changed to output relay 1.
3. Program output relay 1 to desired major or minor alarm to complete programming.
4. Exercise the output relay by causing the alarm to change state.

### **Battery Temperature Compensation**

1. Enable battery temperature compensation if desired.
2. Ensure that battery temperature probe is connected to the system and attached to the battery.
3. Verify that the system voltage is above the float voltage setting if the battery temperature is below 25 degrees C and below the float voltage setting if the battery temperature is above 25 degrees C.

## **4.3. Final Inspection:**

1. Verify that the interior and exterior of the system is clean and free from debris.
2. Ensure all wires connected and bolts are properly tightened.
3. Ensure the following the User, Service, and Calibration parameters are set properly on the controller:

#### LVD

LVD1 Trip

LVD1 Reset

#### Battery Parameters

Discharge Threshold

Float Voltage

Maximum Recharge

Compensation Method

4. Verify that the system is functioning correctly with no alarms.  
Be sure to leave the site as orderly and neat as possible.



## **5      *Technical Description***

---

The Power System is designed to supply safe –54 Vdc primary power through the use of up to 10 rectifier modules. The controller will monitor all functions and provides battery management including controlled battery recharge with temperature compensation and low voltage disconnect. Integrated dc output distribution supports loads ranging from ¼ A all the way to 60 A. The controller can monitor up to 4 discrete external events with voltage free (“dry contact”) user inputs.

### **5.1. Rectifier Management**

#### **AC Input Power**

The basic component of the power system is the rectifier module, which rectifies utility ac into nominal 48 Vdc. Each rectifier module requires 85 – 264 Vac, 47 – 63 Hz single phase power. Available cord sets include a variety of blade and twist lock plugs. Dedicated wiring inside conduit can also be used.

#### **DC Output Power**

The dc outputs of all the rectifiers in the system are connected to a common bus that is rated to carry the current of the entire system. The rectifier modules will equally share the entire load, independent of the controller. The rectifiers will continue to provide dc power (-54.5Vdc) if the controller is removed or fails.

#### **Rectifier alarms reporting**

The rectifier has numerous sensors inside the unit that monitor fan fail, high temperature, high/low voltage, etc. These rectifier sensors trigger outputs that are monitored by the controller. In addition rectifier current is measured inside each rectifier. The controller can trigger output relays in the event of a rectifier alarm. Refer to Section 5.5 for controller functions.

### **5.2. System Management**

#### **System Voltage Monitor and Control**

The controller monitors and adjusts the system voltage. It uses a voltage trim input to the rectifier to precisely control the dc output voltage. In the event of controller removal or failure, individual rectifiers will default to the analog voltage level (-54.5 Vdc) preset at the factory. System high and low voltage alarms are reported by the controller.

## System Current Monitor

The controller monitors individual rectifier currents and displays total system current as a sum of rectifier currents. Load current can be found by adding battery current to system current. Battery Current is positive when the battery is discharging.

Sys Current + Batt current = Load Current

For example, if the battery is charging the Batt Current reading could be (–) 10 A, Sys Current reading could be 50 A. Load Current would be:

Sys Current + Batt current = Load Current  
 $50\text{ A} + (-) 10\text{ A} = 40\text{ A}.$

If the battery is discharging the Batt Current reading could be 10 A, Sys Current reading could be 30 A. Load current would be:

Sys Current + Batt current = Load Current  
 $30\text{ A} + 10\text{ A} = 40\text{ A}.$

## System Status and Alarm Reporting

The controller will monitor system, temperature. The controller reports system high and low temperature alarms.

## 5.3. Load Management

### Circuit Breakers

Distribution is included for up to 2 circuit breakers or eight GMT fuses per 50-A shelf. The circuit breakers can be 2 X 30 A or 1 X 60 A in each shelf. The GMT fuses are 8 X ¼ to 15 A in each shelf. When a circuit breaker trips, a normally open switch closes and the controller reports a CB alarm. Alarms are reported only when a breaker is tripped. When a breaker is turned off, no alarm is generated. Circuit Breaker Alm 1 or 2 are reported when a circuit breaker in the top shelf trips. Circuit Breaker Alm 3 or 4 are reported when a circuit breaker in the bottom shelf trips. Because of this, if a Magnum VS 100 has GMT fuses in the top shelf and 2 circuit breakers in the bottom shelf, the circuit breakers will be labeled CB1 & CB2 on the front panel, but Circuit Breaker Alarm 3 & 4 will be reported. If a Magnum VS 100 has GMT fuses in the top shelf and 1 circuit breaker in the bottom shelf, the circuit breaker will be labeled CB1 on the front panel, Circuit Breaker Alarm 3 will be reported. If a Magnum VS 100 has 1 circuit breaker in the top shelf and 1 circuit breaker in the bottom shelf, the circuit breakers in the bottom shelf will be labeled CB2 on the front panel, but Circuit Breaker Alarm 3 will be reported. To disconnect a load attached to a circuit breaker, move the lever down to the “OFF” position.

## GMT Fuses

When a GMT fuse trips, a fuse element burns out allowing the indicator to connect dc power to the alarm contact. This turns on the fuse alarm LED on the fuse panel indicating the affected group and the controller reports a fuse alarm. Each controller fuse alarm combines alarms from 4 individual fuses:

Fuse F1 to F4 : Fuse Alarm 1.  
Fuse F9 to F12 : Fuse Alarm 3.

Fuse F5 to F8 : Fuse Alarm 2.  
Fuse F13 to F16 : Fuse Alarm 4.

To disconnect a load attached to a GMT fuse pull the fuse straight out of the fuse holder base.

## 5.4. Battery Management

### Battery Charging

Battery charging is integrated into the dc power system to support the primary function of providing power to the load. Accurate measurement of battery parameters such as voltage, current and temperature are used to maintain and protect the batteries attached to the power plant.

Charging the battery at the correct rate reduces battery heating, increases the charge returned to the battery and prevents excess hydrogen generation or, in the case of Valve Regulated Lead Acid (VRLA) batteries, possible thermal runaway. The Magnum VS operates as a current limited constant voltage battery charger. The current limit value is set by the controller's Battery Maximum Recharge Current parameter and is normally based on the size of the battery plant in ampere-hours.

Consult the battery manufacturer for the recommended maximum charging current. This is frequently expressed as a percentage of the battery's 20-hour ampere-hour capacity rating, commonly abbreviated as "C". For example, the maximum recharge current in amperes may be expressed as 0.2C, 20% C or C/5, all of which are equivalent. If the battery used has a capacity of 120 Ah, then the 0.2 C max current is 24 amperes. Manufacturers typically specify max recharge current between 0.1C to 0.3C (C/10 to C/3). Avoid high recharge rates that may induce elevated battery temperatures that can lead to thermal runaway. A 0.1C max recharge current is generally a conservative value that will result in a 90-95% recharge in 12-15 hours, depending on the initial depth of discharge. In this case charging current will begin to taper (reduce) from the current limited value after 3.5 - 7 hours.

Typically four 12-volt batteries are connected in series to form a battery string. The ampere-hour rating for one 12-volt battery will equal the Ah rating of the string. For multiple parallel strings, add the Ah rating of each string together to get the total Ah rating.

## **Battery Equalization**

Battery equalization equalizes the specific gravity of the electrolyte in the cells of a battery. It is accomplished by applying a controlled overcharge to the battery. Equalization may be appropriate (1) after a battery has been in float charge for extended periods time, (2) after a battery has been significantly discharged, or (3) at the time of initial battery installation. There are three methods by which the Magnum VS controller may initiate equalization: manual, periodic and automatic. Manual Equalization is a one time equalization initiated by the user. Periodic Equalization occurs after a set number of days. Automatic Equalization occurs after a set time period of ac power failure or a set percentage of battery ampere-hour discharge. The factory default for all equalization methods is OFF. Refer to the Equalization setup parameters in the table of Section 6.4. The maximum equalization voltage is limited to the system maximum voltage adjustment of -56.5 Vdc.

Presently, the equalization function is only accessible through the controller display keypad. A future upgrade to the network management card is planned that will allow equalization to be accessible remotely.

## **Battery Protection**

An external disconnect should be mounted at the battery string to protect the system from the high energy stored in the battery if a short occurs. The battery LVD will not be energized until a battery string is installed with the proper polarity and the battery disconnect switch is turned on. The battery connections are to be used for the battery only. Do not attach loads to the battery connections or erroneous battery current will be reported. The controller reports Battery high and low voltage alarms and LVD alarms.

## **Battery Temperature Monitoring**

Battery temperature is monitored using a probe attached to the battery casing. The controller reports Battery high and low temperature alarms.

## **Battery Temperature Compensation**

The Battery Float Voltage is set to the value recommended by the battery manufacturer in order to maintain correct battery charge at 25°C. As temperature rises, electrochemical activity in a battery increases. Similarly, as temperature falls, electrochemical activity in a battery decreases. As temperature rises, charging voltage should be reduced to prevent overcharge and possible thermal runaway. As battery temperature falls, voltage is increased to prevent undercharge. The dc power system uses Battery Temperature compensation to change output voltage to compensate for temperature changes monitored at the battery temperature probe. This temperature compensation function is programmed into the controller using the compensation parameters settings. Default settings can be changed to values recommended by the particular battery manufacturer. The controller will not allow the system voltage to be adjusted beyond the range of -47 Vdc to -56.5 Vdc.

## Battery Low Voltage Disconnect

In order to prevent damage to the battery due to deep discharge, the dc power system has hardware and software support for a battery Low Voltage Disconnect (LVD). When the battery voltage reaches the threshold set by the *LVD 1 Trip Voltage* setting during discharge, the dc power system will activate the LVD contactor to disconnect the battery from the system. The LVD will remain open until ac power is restored to the system and the bus voltage reaches the level defined by the *LVD 1 Reset Voltage* variable. The LVD control can be disabled on the LVD parameters screen in the controller.

**NOTE:** The LVD is normally energized and must be commanded to open. This assures that the LVD will remain closed even if the controller fails or is removed.

The LVD will not be energized until a battery string is installed with the correct polarity and the battery disconnect switch is turned on. This will prevent the battery from being hooked up backwards and damaging the rectifiers and/or the loads. Once the battery is connected correctly and the LVD is closed, the LVD will open only in low voltage situations. The battery connections are to be used for the battery only.

## Battery Functional Test

The controller is able to functionally test the battery. This is a short duration test intended to confirm that the battery can deliver current to the load without an unusual drop in system voltage. Excessive voltage drop may be an indication of high resistance electrical connections, high battery internal impedance or impending battery failure. For the test the controller lowers the system voltage sufficiently that the batteries will deliver the current required by the load equipment and thereby start to discharge. The controller monitors the voltage drop to determine if the battery is good or bad. A collapse of voltage will not cause an interruption in power to the load, as the rectifiers remain operational and will continue to support the load if this occurs.

Functional test defaults are a 10 second duration and -48 V pass/fail voltage threshold. Very high or low equipment loads relative to the size of the battery may invalidate the results of this test. Presently this test may only be initiated manually via the controller with display keypad. A future upgrade will add this capability to the network management card for remote access.

## Counter Electro-Motive Force Module Connections

A connection is provided to connect a Counter Electro-Motive Force (CEMF) Module. A CEMF is a semiconductor device connected in series with a battery and used to reduce the voltage to loads that cannot tolerate the “normal” main cell voltage. The CEMF cells are automatically switched out of the circuit when the discharge voltage drops to a predetermined level and are automatically switched back into the circuit when the battery approaches its normal float value.

## 5.5. Controls and Indicators

### Controller with Display

The Magnum VS may be equipped with an optional advanced controller. This controller has an LCD display and a 5-button keypad. This controller uses the normal control card slot as well as the adjacent slot for rectifier 5. Most common parameter monitoring and programming can be made right at the power system using this interface. Any other changes must be made either locally using a PC or remotely by interface to the network management card. Refer to Section 6 for further information. There are five LEDs visible on the control card. The Major LED (Red) is on when the Major Relay is de-energized. The Major Relay is energized when there is no alarm. This will produce a major relay output even when all power is lost. The Minor LED (Yellow) is on when the Minor Relay is energized. The Out Relay LED (Yellow) is on when the Out Relay is energized. The DC OK LED (Green) is on when the voltage is between 50 and 57 Vdc. The green LED behind the front panel is slowly flashing when the controller is processing data.

### Controller without Display

There are no switches or controls of any kind on this controller. All parameter changes or viewing of status is made either locally using a PC or remotely by interface to the network management card. Refer to Section 6 for further information. LED indicators and relay operation is identical to that found on the controller with display.

## 5.6. Alarm Outputs (Output Relays)

There are three alarm output relays designated Out Relay 1, Minor, and Major. Various system parameters may be programmed to activate any of these output relays when set thresholds are exceeded or specific conditions occur. Out Relay 1 can also be routed or “mapped” to “Out Relay 1-6,” “Minor Relay,” “Major Relay” or “Ignore.” This feature makes it possible for a single alarm condition to activate multiple alarm output relays including the Minor or Major alarm relay. For information on making wiring connections to the alarm output relays refer to **Section 3.9**

In addition to the output relays described above there are 5 outputs that do not support actual hardware. These are called Output Relay 2 through 6. While the relay hardware is not available, the programming can still be used to provide more detailed information through the network management card. Using the actual relay 1 and the 5 virtual relays 2-6, six different parameters can be alarmed with unique messages through the network management card. Various system parameters may be programmed to activate any of these output relays when set thresholds are exceeded or specific conditions occur. Relay 2-6 can also be routed or “mapped” to “Out Relay 1-6,” “Minor Relay,” “Major Relay” or “Ignore.”

Out Relay 1-6 can be renamed using the Relay Alias setup screen. Each relay name can be up to sixteen characters in length. This name will appear in the messages generated by the

network management card. This can be used to give specific information on the exact nature of the active alarm.

## **5.7. External Alarm Inputs (User Input)**

The controller can monitor any external device that uses a voltage free (“dry contact”) switch or relay to output status information. The four external user inputs can be routed or “mapped” to alarm output relays. Available assignments are “Ignore”, “Major”, “Minor”, and “Out Relay 1.” For information on wiring connections to these inputs refer to **Section 3.9**

## **5.8. Network Management Card - Local & Remote Monitoring**

The Magnum VS controller includes an APC AP9617 Network Management Card which allows both local and remote access to the power system. The AP9617 is a web-based management product that uses multiple, open standards such as Telnet, HTTP, and SNMP to provide full management of supported devices. The following is a list of some of this Management Card’s features:

- Provides a Data Log accessible by FTP or a Web browser.
- Provides an Event Log accessible by Telnet, FTP, or a Web browser
- Detects connection speed of 10/100 MB per second.
- Generates Email notifications for DC Power Plant events and system events.
- Limits SNMP traps and Email notifications based on the severity level of the DC Power Plant or system events

The Management Card has two internal interfaces (control console and Web interface) which provide menus with options that allow you to manage the DC Power Plant and the Management Card. The Management Card’s SNMP interface also allows you to use an SNMP browser with the PowerNet® Management Information Base (MIB) to manage the DC Power Plant.

### 6.1. Description

The Magnum VS is designed for years of operation with no user input. The power system is pre-programmed at the factory with all parameters needed for normal operation. The front panel LEDs and the alarm output relays, indicate the general health of the unit. There are 2 controllers available for this power system. A LCD display with keypad (0M-2997) will access most operator functions from the front of the unit. This controller is described in more detail in Section 6.3. A controller without display (0M-1650) is described in more detail in Section 6.5. This controller requires local parameter changes to be made using a PC.

### 6.2. Controller Card Jumpers

#### System voltage J5

The positioning of jumpers on header J5 will determine the operating voltage of the controller card operates. Options include –48 V, +24 V, +48 V, or –24 V systems. The Magnum VS is only a –48 V system. The only setting allowed is the –48 V setting, which is J5-1 jumpered to J5-6 and J5-2 jumpered to J5-7.

#### Remote Lockout J8

It is possible to make parameter changes to the controller card through the RS232 port or through the 10/100 Base T port of the network management card. The controller card is shipped with a jumper between pins J8-2 and J8-3, allowing such parameter changes. If the user wishes to disable the remote configuration feature, then the jumper is moved to pins J8-1 and J8-2.


#### Firmware Programming Enable J9

When the operating system is initially installed at the factory, J9-1 is jumpered to J9-2. This setting interferes with normal operation. To ensure normal operation, the controller card is shipped without this jumper. During normal operation, the only setting allowed is no jumper between J9-1 and J9-2.

#### Vtrim Trip Select J13

The header J13 is a factory set header that allows this controller to work with different types of rectifiers. The Magnum VS always uses the Magnum VS rectifier. During normal operation, the only setting allowed is J13-2 jumpered to J13-3.





**Figure 6.2-1 Controller Card Jumper Locations**

### 6.3. Controller with Display

Refer to Figure 6.3-1 for the front panel layout. The keypad consists of five buttons: ↑, ↓, ↵ (Enter), ESC (Escape) and “?” or Help key. The displays available consist of selection menus, informational displays and editable displays.

**Selection Menus** – permit the display of multiple items. The up and down keypads allow the user to scroll up and down among the selections. The item indicated by the right carrot is the pre-selected item. The ↵ selects the function and the display changes to that item. The ESC keypad will take you back to the previous menu.

**Information displays** – display power plant information in a preformatted display. The information is dynamic.

**Editable Displays** – permit the change of certain parameters within the power plant. The PIN or password will need to be entered before parameters can be changed. Once the PIN is entered it will not be required to be entered a second time that session. The up, down and enter keys are used to modify the value.

The screen will revert to the language selection screen after a controller reset. Choices are English and Chinese.

If the keypad is not pressed for approximately 2 minutes the display will revert to the Status display and the backlight will extinguish. It will also clear any PIN that may have been entered. Pressing any key during this mode will cause the display of the Main Menu and permit navigation among the menus.




Figure 6.3-1 Controller with Display

## 6.4. Operation using Local Display and Keypad Interface

The location, description, and factory programmed default value for each of the Magnum VS system parameters is found in the table below. The menu location of a parameter screen is shown in brackets, for example: **[STATUS/RECT/Rect xx]**. This table is organized alphabetically by parameter name.

Figure 6.4-1 Parameter Locations, Descriptions, and Default Values

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default Settings in BOLD)
Alarms Item 1 {Status Only} [ALARMS] [告警]	Display of up to 16 active alarms. Scroll up or down to select individual alarms.	Alarm Status Only
Battery Capacity [SETUP/BATTERY/ CAP] [设置 / 电池 / 容量]	The total battery capacity in ampere-hours of the entire battery array. Normally specified at 20 hour discharge rate.	0Ah – 10,000 Ah, <b>0 Ah</b>
Battery Current {Status Only} [STATUS/BATTERY/ PARAMETERS] [状态 / 电池 / 参数]	Battery current measured by the system controller at the battery current shunt.	Battery Current Status Only
Battery Float Voltage [SETUP/BATTERY/ VOLTAGE/FLOAT] [设置 / 电池 / 电压 / 浮充]	One of three parameters that control the dc output voltage. Set the Float Voltage to the desired 25°C battery temperature per the battery manufacturers recommendations.	-56.5V - -47.0V, <b>-54.00 V</b> ,
Battery Functional Test [SETUP/BATTERY/TEST] [设置 / 电池 / 测试]	Lowers the system voltage so a discharge test of the battery is performed. ON – initiates a battery test. Off – stops a test in progress.	ON, <b>OFF</b>
Battery Functional Test Result [STATUS/BATTERY/TEST] [状态 / 电池 / 测试]	Displays the results of the last battery test.	FAIL, PASS, INTERRUPTED, IN PROCESS, NOT PERFORMED
Battery Maximum Recharge Current [SETUP/BATTERY/CURRENT] [设置 / 电池 / 电流]	One of three parameters that control the dc output voltage. If Battery Current surpasses the Maximum Battery Recharge Current, the dc output voltage will be reduced (the system limits the charging current to this programmable value).	0 – 500 A, <b>5 A</b>
Battery Mode Status [STATUS/BATTERY/MODE] [状态 / 电池 / 模式]	This will display the condition of the battery. Float is normal operation. Discharge means the rectifiers are not producing enough current and the batteries are discharging. Equalizing means the voltage is above float voltage to give the batteries an equalize charge.	Float, Equalizing or Discharge.

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default Settings in BOLD)
Battery Temperature [STATUS/BATTERY/ PARAMETERS] [状态 / 电池 / 参数]	Battery temperature measured by the system controller at the optional battery temperature sensor probe.	Battery Temperature Status Only
Date Setup [SETUP/SYSTEM/TIME/DATE] [设置 / 系统 / 时/日]	System date stored in the controller. Used as a date stamp in the event log.	Current DATE
Date Status [STATUS/SYSTEM/Time/Date] [状态 / 系统 / 时/日]	Displays the current controller date.	Date Status Only
Equalize Automatically On/Off [SETUP/BATTERY/ VOLTAGE/EQUALIZATION/ METHOD/AUTO] [设置 / 电池 / 电压 / 均充 / 模式 / 自动]	Applies an overcharge to the battery to equalize the specific gravity of a battery. Auto equalization is initiated when the controller determines that the batteries have been discharged a set percentage of their capacity or the batteries have been on discharge for a set duration. Use this screen to turn auto equalization on.	ON, <b>OFF</b>
Equalize Automatically on AC Fail [SETUP/BATTERY/ VOLTAGE/EQUALIZATION/ METHOD/AUTO/AC FAIL/ON/OFF] [设置 / 电池 / 电压 / 均充 / 模式 / 自动 /自动]	Sets the time the ac input power has to be off before equalization occurs.	15 MINUTES – 360 MINUTES, <b>15 MINUTES</b>
Equalize Automatically on Battery Discharge [SETUP/BATTERY/ VOLTAGE/EQUALIZATION/ METHOD/AUTO/DISCHARGE] [设置 / 电池 / 电压 / 均充 / 模式 / 自动 / 交流故障]	Sets the percent of battery discharge before equalization occurs. Percent Discharge = Discharged ampere-hours / Battery Capacity ampere-hours	5% - 50%, <b>30 %</b>

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default Settings in BOLD)
Equalization Duration [SETUP/BATTERY/ VOLTAGE/EQUALIZATION/ DURATION] [设置 / 电池 / 电压 / 均充 / 均充时间]	This setting defines the number of hours the batteries will be equalized in all methods of equalization. During the initial stage of equalization the batteries will have to be increased to the equalization voltage. Once the battery voltage and current meet equalization parameters, the equalization duration timer will start.	00 HOURS- 24 HOURS, <b>0 HOURS</b>
Equalize Manually [SETUP/BATTERY/ VOLTAGE/EQUALIZATION/ METHOD/MANUAL] [设置 / 电池 / 电压 / 均充 / 模式 / 手动]	Applies an overcharge to the battery to equalize the specific gravity of a battery. Manual equalization is a one-time equalization process. The operator turns on manual equalization each time he wishes an unscheduled equalization to occur. To abort an automatic or periodic equalization in progress, turn manual equalization ON and then OFF.	ON, <b>OFF</b>
Equalize Periodically [SETUP/BATTERY/ VOLTAGE/EQUALIZATION/ METHOD/PERIODIC] [设置 / 电池 / 电压 / 均充 / 模式 / 周期]	Applies an overcharge to the battery to equalize the specific gravity of a battery. Periodic equalization is equalization after a set number of days.	ON, <b>OFF</b> ; 0-180 Days, <b>180 Days</b>
Equalization Voltage [SETUP/BATTERY/ VOLTAGE/EQUALIZATION/ VOLTAGE] [设置 / 电池 / 电压 / 均充 / 电压]	The overcharge voltage that will be applied to the battery	-56.5 V - -48.0 V, <b>-56.0 V</b>
Language Selection	The screen will revert to the language selection screen after a reset. Choices are English and Chinese.	
Pin Entry [SETUP] [设置]	Enter PIN to access setup menus. Entering setup brings you to the PIN entry screen. In-activity for two minutes will de-activate system access.	0000 – 9999, <b>2222</b>
PIN Setup [SETUP/SYSTEM/SET PIN] [设置 / 系统 / 码设置]	Change PIN that the user will use to log on to the system. If you change the PIN, Do Not Forget It.	0000 – 9999, <b>2222</b>
Rectifier Current Limit Status {Status Only} [STATUS/RECT] [状态 / 模块]	A display of the current limit alarm for the individual rectifier. Scroll up or down to select individual rectifiers.	Rectifier Current Limit Status Only

<b>PARAMETER NAME/ [MENU LOCATION]</b>	<b>DESCRIPTION</b>	<b>SETTINGS (Default Settings in BOLD)</b>
Rectifier Current Output Status {Status Only} <b>[STATUS/RECT]</b> [ 状态 / 模块]	A display of the dc output current for the individual rectifier. Scroll up or down to select individual rectifiers.	Rectifier Current Output Status Only
Rectifier Fan Fail Status {Status Only} <b>[STATUS/RECT]</b> [ 状态 / 模块]	A display of the fan fail alarm for the individual rectifier. Scroll up or down to select individual rectifiers.	Rectifier Fan Fail Status Only
Rectifier Fail Alarm (RFA) Status {Status Only} <b>[STATUS/RECT]</b> [ 状态 / 模块]	A display of the RFA alarm for the individual rectifier. Scroll up or down to select individual rectifiers.	Rectifier Fail Alarm Status Only
System Current {Status Only} <b>[STATUS/SYSTEM/ Parameters]</b> [状态 / 系统 / 参数]	The total system output current (calculated as the sum of the individual rectifier output currents).	System Current Status Only
System Temperature {Status Only} <b>[STATUS/SYSTEM/ Parameters]</b> [状态 / 系统 / 参数]	System temperature measured within the controller.	System Temperature Status Only
System Voltage {Status Only} <b>[STATUS/SYSTEM/ Parameters]</b> [状态 / 系统 / 参数]	Actual power plant output voltage measured by the controller at the output of the rectifiers. This is the same voltage at the front panel test points of the controller.	System Voltage Status Only
Time Setup <b>[SETUP/SYSTEM/Time/Date]</b> [设置 / 系统 / 时/日]	System time stored in the controller. Used as a date stamp in the event log.	Current Time
Time Status <b>[STATUS/SYSTEMTime/Date]</b> [状态 / 系统 / 时/日]	Displays the current controller time.	Time Status Only




Figure 6.4-2 Magnum VS English Display Tree




Figure 6.4-3 Magnum VS Chinese Display Tree



## 6.5. Controller without Display

This controller does not have a built in display and keypad. It does not use the fifth rectifier slot. All parameter changes or viewing of status is made either locally using a PC or remotely by interface to the network management card. Refer to Figure 6.5-1 for the front panel layout.




Figure 6.5-1 Magnum VS Controller without Display

## 6.6. Operation Using the RS-232 Comm Port

The front panel DB-9 connector provides a means to connect a PC to the controller locally to set controller parameters and to view status. To connect to this port use a straight through cable such as APC part number 0129-XX. A 0129-6 is included with this manual. Refer to the Network Management Card Quick Start Manual or the User's Guide supplied on the CD shipped with the system for details on how to communicate to the controller using a terminal emulation program like HyperTerminal(TM) or Procomm(TM).

**NOTE:** The smart-signaling cable (940-0024 or 940-1524) referenced in the Quick Start Manual and User's Guide does not apply to the Magnum VS. Use a straight through cable such as APC part number 0129-XX. A 0129-6 is included with this manual.

Communication to the controller through the local serial port is accomplished via the network management card's Control Console interface. This is a simple text based menu interface.

## 6.7. Operation Using the 10/100 BaseT Ethernet Port

The RJ-45 10/100 Base-T port is primarily intended for connection to an intranet for remote access to the DC power system. However with the use of a crossover cable or a hub, a direct PC to 10/100 Base-T local connection may also be made.

After the Management Card is configured and running on your network, you can use several different interfaces to access the Management Card: Web, Telnet, SNMP and FTP.

- The Web interface uses a web browser such as Microsoft ® Internet Explorer 5.0 (and higher) or Netscape ® 4.0.8 (and higher) to configure Management Card options and to view DC power system status, alarms and events.

- Telnet is used to access a Management Card's Control Console and is the same user interface available via the local RS-232 serial port.

- SNMP access is available after you add the PowerNet MIB to a standard SNMP MIB browser.

- FTP access is used to download new firmware to a Management Card, or to access a copy of a Management Card's event or data logs.

Complete documentation for the use of the management card accompanies the DC power system in the form of a Quick Start Guide and a CD. The CD contains electronic copies of User's Manuals along with the necessary software utilities to support the management function. Some of the functions supported by the network card are not supported by this power system.

## 6.8. Operation using Network Management Card Web Browser Interface

The location, description, and factory programmed default value for each of the Magnum VS system parameters accessible via a Web browser is found in the table below. The table also shows all of the status and information screens with typical displays. The location of a parameter screen is shown in brackets, for example: **[Power Modules/Rectifiers]**. This table is organized alphabetically by parameter name.

Figure 6.8-1 Parameter Locations, Descriptions, and Settings

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default settings in <b>BOLD</b> )
Alarms Item 1 {Status Only} [System/Active Alarms] • • • Alarms Item 16 [System/Active Alarms]	Display of up to 16 active alarms (a typical alarm screen is shown). • • • Display of up to 16 active alarms (a typical alarm screen is shown).	No Alarms • • • No Alarms
Battery Current {Status Only} [System/DC Parameters]	Battery current measured by the system controller at the battery current shunt.	Status Only
Battery Discharge Alarm [Batteries/Parameters]	Defines the output relay that is energized if the battery discharge current exceeds the programmed battery discharge threshold.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Battery Discharge Threshold [Batteries/Parameters]	An alarm is generated if the battery discharge current exceeds this value.	0 A – 20A, <b>5 A</b>
Battery Float Voltage [Batteries/Parameters]	One of three parameters that control the dc output voltage. Set the Float Voltage at 25°C battery temperature per the battery manufacturers recommendations.	-56.5 – -47.0, <b>-54.00 V</b>
Battery High Temperature Alarm [Batteries/Parameters]	Defines the output relay that is energized if the battery temperature exceeds the Battery High Temperature threshold.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Battery High Temperature Threshold [Batteries/Parameters]	Battery Temperature is temperature measured at the battery probe. An alarm is generated if the battery temperature exceeds this value.	-100 °C – 200 °C, <b>40.0 °C</b>
Battery High Voltage Alarm [Batteries/Parameters]	Defines the output relay that is energized if the dc output voltage rises above the battery high voltage threshold.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Battery High Voltage Threshold [Batteries/Parameters]	An alarm will be reported if temperature is lower than the temperature entered. An alarm is generated if the dc output voltage rises above this value.	-40.00 V – -60.00 V, - <b>58.00 V</b>
Battery Low Temperature Alarm [Batteries/Parameters]	Defines the output relay that is energized if the Battery Temperature drops below the battery Low Temperature threshold.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Battery Low Temperature Threshold [Batteries/Parameters]	Battery Temperature is temperature measured at the battery probe. An alarm is generated if the battery temperature drops below this value.	-100 °C – 200 °C, <b>-20.0 °C</b>
Battery Low Voltage Alarm [Batteries/Parameters]	Defines the output relay that is energized if the dc output voltage drops below the battery low voltage threshold.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Battery Low Voltage Threshold [Batteries/Parameters]	An alarm is generated if the dc output voltage drops below this value.	-40.00 V – -60.00 V, <b>-44.00 V</b>

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default settings in BOLD)
Battery Max Recharge {Status Only} [System/DC Parameters]	This is just a convenient place to view the Battery Max Recharge Current parameter. Go to Batteries/Parameters to change setting.	Status Only
Battery Maximum Recharge Current [Batteries/Parameters]	One of three parameters that control the dc output voltage. If Battery Current surpasses the Maximum Battery Recharge Current, the dc output voltage will be reduced (the system limits the charging current to this programmable value).	0 – 10,000 A, <b>10 A</b>
Battery Temperature [System/DC Parameters]	Battery temperature measured by the system controller at the optional battery temperature sensor probe.	Status Only
Battery Temperature Compensation High Knee [Batteries/Parameters]	The temperature compensation high knee is the point where there is no additional battery voltage compensation for further increases in temperature.	0 °C – 100 °C, <b>40.0 °C</b>
Battery Temperature Compensation Low Knee [Batteries/Parameters]	The temperature compensation low knee is the point where there is no additional battery voltage compensation for further decreases in temperature.	-100 °C – 100 °C, <b>0.0 °C</b>
Battery Temperature Compensation Method [Batteries/Parameters]	One of three parameters that control the dc output voltage. Activate “ON” or deactivate “OFF” battery temperature compensation.	<b>ON</b> , OFF
Battery Temperature Compensation Temperature Coefficient [Batteries/Parameters]	Temperature compensation coefficient between low knee and high knee in mV/cell/°C. (Compensation equals zero at 25°C.)	-4.99 mV – 0 mV, <b>-3.00mV</b>
Circuit Breaker 1 Alias [Distribution/Breakers] • • • Circuit Breaker 4 Alias [Distribution/Breakers]	An alternate name (alias) can be assigned to Circuit Breaker 1 if desired. This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	Circuit Breaker 1  • • • Circuit Breaker 4
Circuit Breaker 1 Tripped [Distribution/Breakers] • • • Circuit Breaker 4 Tripped [Distribution/Breakers]	Defines the output relay that is energized when Circuit Breaker 1 is tripped. • • • Defines the output relay that is energized when Circuit Breaker 4 is tripped.	Ignore, Minor, <b>Major</b> Output Relay 1-6 • • • Ignore, Minor, <b>Major</b> Output Relay 1-6 Circuit Breaker 5-72 is not used in this system.
Communications Fail	Defines the output relay that is energized if the System stops communicating with the rectifiers. This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	<b>Ignore</b> , Minor, Major Output Relay 1-6•

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default settings in BOLD)
Current Limit Alarm Status {Status Only} [Power Modules/Rectifiers]	The status will be "ON" if the rectifier has been forced into its current limited mode.	Status Only
Date [System/Date & Time]	Internal network management card calendar date. Used as a date stamp in the web card event log.	Current Date
Description 1 [System/DC Parameters]	Power plant identification - first line.	
Description 2 [System/DC Parameters]	Power plant identification - second line.	Magnum VS This is not user edit-able.
Description 3 [System/DC Parameters]	Power plant identification - third line.	Power System This is not user edit-able.
Fail Safe [Power Modules/Rectifiers]	If the rectifiers fail to communicate with the system, the rectifiers will output this pre-defined voltage.	This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.
FUSE 1 Alias [Distribution/Fuses] • • • FUSE 1 Alias [Distribution/Fuses]	An alternate name (alias) can be assigned to Fuse 1 if desired. This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	FUSE 1  • • • FUSE 16
FUSE 1 Blown [Distribution/Fuses] • • • FUSE 4 Blown [Distribution/Fuses]	Defines the output relay that is energized when F1-4 is blown. • • • Defines the output relay that is energized when F13-16 is blown.	Ignore, Minor, <b>Major</b> Output Relay 1-6 • • • • Ignore, Minor, <b>Major</b> Output Relay 1-6 Fuse 5-16 is not used in this system
Hardware Battery Current Alarm [Batteries Parameters]	Defines the output relay that is energized if there is a hardware failure in the battery current monitoring function. This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	<b>Ignore</b> , Minor, Major Output Relay 1-6
Hardware Battery Temperature Alarm [Batteries Parameters]	Defines the output relay that is energized if there is a hardware failure in the battery temperature monitoring function. Program to Ignore if no battery temperature probe is connected to J410.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Hardware LVD Alarm [Batteries/LVD]	Defines the output relay that is energized if there is a conflict between the commanded and sensed positions of the LVD contactor. This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	<b>Ignore</b> , Minor, Major Output Relay 1-6

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default settings in BOLD)
Hardware System Voltage Alarm [Power Modules/Rectifiers]	Defines the output relay that is energized if there is a hardware failure in the system voltage monitoring function.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Hardware Temperature Alarm [System/DC Parameters]	Defines the output relay that is energized if there is a hardware failure in the system temperature monitoring function.	Ignore, <b>Minor</b> , Major Output Relay 1-6
High Temperature Alarm [System/DC Parameters]	Defines the output relay that is energized if the System Temperature exceeds the system high temperature threshold. Not the same as battery temperature alarm.	Ignore, <b>Minor</b> , Major Output Relay 1-6
High Temperature Threshold [System/DC Parameters]	Ambient temperature measured inside the controller. An alarm will be reported if temperature is higher than the temperature entered. Not the same as battery temperature threshold.	0 °C – 100 °C, <b>70.0 °C</b>
High Voltage alarm [Power Modules/Rectifiers]	Defines the output relay that is energized if the System Voltage is above the System High Voltage threshold. Not the same as battery voltage alarm.	Ignore, <b>Minor</b> , Major Output Relay 1-6
High Voltage Threshold [Power Modules/Rectifiers]	DC voltage measured by the controller. An alarm will be reported if voltage is higher than the voltage entered. Not the same as battery voltage threshold.	-60 V – -40 V, <b>-58.00 V</b>
Imbalance Alarm [Power Modules/Rectifiers]	An alarm will be generated if the rectifiers do not current share. This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	<b>Ignore</b> , Minor, Major Output Relay 1-6
Input Relay 1 [I/O/Input]  • • • Input Relay 4 [I/O/Input]	Defines the output relay that is energized when an external contact closure or opening at the Input Relay 1 connection changes state.  • • • Defines the output relay that is energized when an external contact closure or opening at the Input Relay 4 connection changes state.	<b>Ignore</b> , Minor, Major Output Relay 1-6  • • • <b>Ignore</b> , Minor, Major Output Relay 1-6
Input Relay 1-4 Alias [I/O/Input]	This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	Input 1-4
Input Relay 1-4 Delay [I/O/Input]	This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	<b>0.00 Seconds</b>
Low Temperature Alarm [System/DC Parameters]	Defines the output relay that is energized if the System Temperature is below the System Low Temperature threshold. Not the same as battery temperature alarm.	Ignore, <b>Minor</b> , Major Output Relay 1-6

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default settings in BOLD)
Low Temperature Threshold [System/DC Parameters]	System Temperature is ambient temperature measured inside the controller. An alarm will be reported if temperature is lower than the temperature entered. Not the same as battery temperature threshold.	-100 °C – 100 °C, <b>0.0 °C</b>
Low Voltage Alarm [Power Modules/Rectifiers]	Defines the output relay that is energized if the System Voltage is below the System Low Voltage threshold. Not the same as battery voltage alarm.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Low Voltage Threshold [Power Modules/Rectifiers]	System Voltage is bus voltage measured by the controller. An alarm will be reported if voltage is lower than the voltage entered. Not the same as battery voltage threshold.	-60 V – -40 V, <b>-50.00 V</b>
LVD 1 Option [Batteries/LVD]	If the unit has an LVD, but it is disabled, the controller will not disconnect the LVD.	<b>Enable</b> , Disable
LVD 1 Reset [Batteries/LVD]	LVD Reset (reconnect) threshold voltage.	-56 V – -40 V, <b>-50.00 V</b>
LVD 1 Trip [Batteries/LVD]	LVD Trip (disconnect) threshold voltage.	-56 V – -40 V, <b>-42.00 V</b>
LVD 2 Option [Batteries/LVD]	Not available on this system.	<b>Disable</b>
LVD 2 Reset [Batteries/LVD]	Not available on this system.	0.00 V
LVD 2 Trip [Batteries/LVD]	Not available on this system.	0.00 V
LVD Alarm [Batteries/LVD]	Defines the output relay that is energized when the controller opens the LVD. If unit has a battery LVD, no power will be available to turn on any Output Relays.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Output Relay 1 Alarm [I/O/Output]	Output Relay 1 Alarm can be “mapped” to activate other output relays (“Ignore” activates no additional relays).	<b>Ignore</b> , Minor, Major Output Relay 1-6
Output Relay 2 Alarm [I/O/Output] • • • Output Relay 6 Alarm [I/O/Output]	Output Relay 2-6 Alarm can be “mapped” to activate other output relays (“Ignore” activates no additional relays). Alarms that are mapped to output relay 2-6 are not supported by hardware. The network management card supports programming these relays. These relays can be mapped to the hardware relays minor and major.	<b>Ignore</b> , Minor, Major Output Relay 1-6 • • • <b>Ignore</b> , Minor, Major Output Relay 1-6

PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default settings in BOLD)
Output Relay 1 Alias [System/Out-Rly/Alias] • • • Output Relay 6 Alias [System/Out-Rly/Alias]	An alternate name (alias) can be assigned to Output Relay 1 if desired.  • • An alternate name (alias) can be assigned to Output Relay 6 if desired.	<b>Output Relay 1</b>  • • • <b>Output Relay 6</b>
Output Relay 1 Delay [I/O/Output] • • • Output Relay 6 Delay [I/O/Output]	Delay between sensing of the alarm condition and activation of the mapped relay. An alarm condition must exist for longer than the delay to be activated.	0.00 seconds – 600.00 seconds, <b>0.00 seconds</b>
Rectifier 1-of-N Alarm [Power Modules/Rectifiers]	Defines the output relay that is energized if Rectifier Fail 1-of-N alarm occurs. This is a special rectifier alarm group that signifies that one rectifier has at least one alarm condition.	Ignore, <b>Minor</b> , Major Output Relay 1-6
Rectifier 2-of-N Alarm [Power Modules/Rectifiers]	Defines the output relay that is energized if Rectifier Fail 2-of-N alarm occurs. This is a special rectifier alarm group that signifies that more than one rectifier has at least one alarm condition.	Ignore, Minor, <b>Major</b> Output Relay 1-6
Rectifier Configuration Alarm [Power Modules/Rectifiers]	Defines the output relay that is that is energized a rectifier is added to any empty slot after the dc system is powered up or configured. This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	Ignore, Minor, Major Output Relay 1-6, <b>n of N</b>
Rectifier Current Limit Alarm [Power Modules/Rectifiers]	Defines the output relay that is energized or special rectifier alarm group n of N that occurs when a rectifier has been forced into the current limited mode.	Ignore, Minor, Major Output Relay 1-6, <b>n of N</b>
Rectifier Current Output Status {Status Only} [Power Modules/Rectifiers]	A display of the dc output current for the individual rectifier.	Status Only
Rectifier Description {Status Only} [Power Modules/Rectifiers]	Displays the model number of the installed rectifier.	Status Only
Rectifier Diagnostic Alarm [Power Modules/Rectifiers]	This feature is not needed in this particular configuration.	<b>Ignore</b> , Minor, Major Output Relay 1-6, <b>n of N</b>
Rectifier Fan Fail Alarm [Power Modules/Rectifiers]	Defines the output relay that is energized or special rectifier alarm group n of N that occurs when a rectifier fan has failed.	Ignore, Minor, Major Output Relay 1-6, <b>n of N</b>
Rectifier Fan Fail Alarm Status {Status Only} [Power Modules/Rectifiers]	The status will be “ON” if the rectifier fan has failed.	Status Only



PARAMETER NAME/ [MENU LOCATION]	DESCRIPTION	SETTINGS (Default settings in BOLD)
Rectifier Fault Alarm (RFA) Status {Status Only} [Power Modules/Rectifiers]	The status will be on if the rectifier output has failed.	Status Only
Rectifier RFA Alarm [Power Modules/Rectifiers]	Defines the output relay that is energized or special rectifier alarm group n of N that occurs when a rectifier output has failed.	Ignore, Minor, Major Output Relay 1-6, <b>n of N</b>
Rectifier Standby Alarm [Power Modules/Rectifiers]	Defines the output relay that is that is energized or special rectifier alarm group n of N that occurs when the controller is holding a rectifier in the standby mode.	Ignore, Minor, Major Output Relay 1-6, <b>n of N</b>
Rectifier Standby Alarm Status {Status Only} [Power Modules/Rectifiers]	The status will be "ON" if the controller is holding the rectifier in the standby mode.	This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.
Remote Configurable [System/DC Parameters]	This allows settings to be made using the SNMP interface card. Disabling this feature allows changes to be made through the local interface only. Status and parameters are still displayed.	<b>Enabled</b> , Disabled
Store Configuration [Power Modules/Rectifiers]	This feature is supported by the standard SNMP card monitor, but is not supported by this dc system.	Enable, <b>Disable</b>
System Current {Status Only} [System/DC Parameters]	The total system output current (calculated as the sum of the individual rectifier output currents).	Status Only
System Temperature {Status Only} [System/DC Parameters]	System temperature measured within the controller.	Status Only
System Voltage {Status Only} [System/DC Parameters]	Voltage readout measured by the controller at the output of the rectifiers. This voltage is based on calculations performed by the controller based on the Battery Float, Battery Temperature Compensation and Battery Maximum Recharge parameter settings.	Status Only
Temperature Display Units [System/Preferences]	Enables selection of Fahrenheit or Celsius temperature scale (Fahrenheit "OFF" displays readings in °C).	Fahrenheit, <b>Celsius</b>
Time [System/Date & Time]	Network management card Internal system clock time (24-hour format). Used as a time stamp in the web card event log.	Current Time

## 6.9. LVD Operation

In order to prevent damage to the battery due to deep discharge, the dc power system has a Low Voltage Disconnect (LVD). When the battery voltage reaches the threshold set by the *LVD 1 Trip Voltage* setting during discharge, the dc power system will activate the LVD contactor to disconnect the battery from the system. The LVD will remain open until ac power is restored to

the system and the bus voltage reaches the level defined by the *LVD 1 Reset Voltage* variable. The LVD control can be disabled on the LVD parameters screen in the controller.

The LVD will not be energized until a battery string is installed with the correct polarity and the battery disconnect switch is turned on. This will prevent the battery from being hooked up backwards and damaging the rectifiers and/or the loads. Once the battery is connected correctly and the LVD is closed, the LVD will open only in low voltage situations. The battery connections are to be used for the battery only.

## 6.10. Programming Output Relays

Any alarm condition such as System High Voltage Alarm, Battery Discharge Alarm or Rectifier 1 of n Alarm can be programmed to any of the eight output relays. Programming alarms to the output relays 1-6 will give a much better idea of what the failure is before actually visiting the site. Using the default programming, over twenty conditions could cause activate a minor relay. However, if you program Battery Discharge Alarm to Output Relay 1, you will know exactly what the alarm is just by knowing that output relay 1 is on. The network management card also displays the output relays individually and can be set up to e-mail these messages.

Output relay mapping options are Ignore, Major, Minor and Output Relay 1-6. To program the alarm to an output relay find the alarm setup screen for the desired alarm from the table in Figure 6.8-1. The Ignore setting will not send an alarm to any display or relay. Programming the alarm to Major, Minor or Output Relay 1 will send the alarm to the relay output connector on the back of the plant, turn on the appropriate front panel LED, and will send the alarm to the network management card. Programming the alarm to Output Relay 2-6 will not send the alarm to the relay output connector on the back of the plant, but will turn on the front panel Out Relay LED, and will send the alarm to the network management card. For instance, go to the Batteries / Parameters screen and program Battery Discharge Alarm to Output Relay 1. When the battery discharge current goes above the default setting of 5 Amps, the alarm will come on, the Out Relay contact will energize, the front panel Out Relay LED will come on and the network management card will report Output Relay 1 is on.

Most alarms are originally assigned to a minor or major relay. Usually it is desirable to keep the minor and major assignments when programming to the output relays. To do this, go to the output relay-programming screen and map the relay back to the desired minor or major relay. For instance, go to the I/O / Output screen and program Relay 1 to Minor Relay. When the battery discharge current goes above the default setting of 5 Amps, the alarm will come on, the Out Relay contact will energize, the Out Relay LED will come on and the network management card will report Output Relay 1 is on. In addition, the Minor Relay contact will energize, the front panel Minor LED will come on and the network management card will report the Minor Relay is on. With this scheme of programming, you will know that you have a minor alarm and specifically that the batteries are discharging.

Out Relay 1-6 can be renamed using the Relay Alias setup screen. Each relay name can be up to sixteen characters in length. This name will not appear in the alarm summary, but will appear in the messages generated by the network management card. This can be used to give specific

information on the exact nature of the active alarm. Using the example above, if you use the default programming the message “A minor relay in the power plant has been activated.” Using the relay mapping and aliasing you could get the additional message “An output relay (1, Batt Discharge) for the power plant has been activated.

## 7 Preventive Maintenance

Preventive Maintenance is typically performed on a quarterly basis.

### 7.1. Equipment

1. 4 Digit voltmeter.
2. Clamp-on ampere meter.
3. Standard Insulated tools.

### 7.2. Inspection

#### Environmental Inspection

1. Ensure the dc system environment is suitable for operation.
2. Ensure that there is sufficient clearance around the system for service.
3. Ensure that there is no sign of damage to the dc system.
4. Contact monitoring personnel or disable system alarms before servicing the unit. This will allow the unit to be serviced without creating false alarms.

#### System Visual and Safety Inspection



**WARNING:** Hazardous energy levels are present on bare conductors in the dc distribution connection area of the plant. Accidental shorting of distribution conductors can cause arcing and high currents that can cause serious burns or other physical harm. It is recommended that:

- Any jewelry, rings or watches be removed while working on this equipment.
- Handles of all wrenches, screwdrivers, cutters and pliers are insulated.

1. Ensure that the dc wiring is properly installed, sized, terminated and identified.
2. Ensure that the ac wiring is properly installed, sized, terminated and identified.
3. Ensure that the battery wiring is properly connected to the System.
4. Ensure that the dc output over-current protection devices are adequate for the size of wiring installed.
5. Ensure that the dc Positive is bonded to central office ground (- 48 volt system).
6. Note the resistance of the ground bond.
7. Note any currents flowing in the ground.
8. Record ambient temperature.
9. Verify that the battery polarity is correct.
10. If battery disconnect devices are present, note the following for each device:
  - a) DC voltage rating.
  - b) DC current rating

### c) Interrupting Current Rating

## **Battery Visual and Safety Inspection**

1. Check that the battery temperature probe is firmly attached to the battery.
2. Check the mechanical integrity of the battery framing, racking, or cabinet. Tighten where necessary.
3. If there is a battery disconnect device fitted, ensure that it is properly connected and protected.
4. Check the general appearance and cleanliness of the battery. Clean if necessary. Use only approved cleaning materials.
5. Visually inspect each cell for the following, and clean and neutralize if necessary. Document discrepancies on Site form accordingly.
  - a. Cracks.
  - b. Case leaks.
  - c. Post-seal leaks.
  - d. Pressure relief valve leaks (VRLA only).
  - e. Case swelling (VRLA only).
  - f. Terminal corrosion and connector corrosion.
6. Check the torque of all battery inter-cell connector in accordance with specifications. Re-torque if necessary (annual only).
7. Measure and record ambient temperature.

## **7.3. Test**

### **System Voltage Test**

1. Verify with a voltmeter directly attached to the dc bus that the system voltage is correct.
2. System voltage should also agree with the battery float voltage set up in the battery parameters section. Be sure to take into account the effects of temperature compensation and battery recharge current limit.

### **Rectifier Current Share Test**

Verify that the highest rectifier current and the lowest current are within 5 A of each other.

### **System Current Test**

Verify the System current equal to the total of the rectifier currents. System current should equal the total current of the loads as well as any battery current.

### **Rectifier Alarm Test**

1. Verify that all of the rectifiers report RFA Alarm is off.
2. Remove 1 rectifier and verify that you get a Minor alarm for Rect 1 of n failure on the controller and the customer remote alarm panel.

3. Remove the second rectifier and verify that you get a Major alarm for Rect 2 of n failure on the controller and the customer remote alarm panel.
4. After the fan has completely stopped spinning, insert a plastic pen or plastic screwdriver into the fan blade of one of the rectifiers and reinsert both rectifiers
5. Verify that you get the fan fail alarm on controller and the customer remote alarm panel.
6. Remove the fan fail device.

### **System Temperature Test**

Verify that the system temperature is correct.

### **Battery Current Test**

1. Measure the battery current with a clamp-on meter.
2. Verify that the battery current is below 5 A.
3. Verify that the displayed battery current is within  $\pm 5$  A.
4. Determine the total battery capacity at the site:  
Cells connected in series make up a string, and the capacity is determined by the capacity of a single cell. Add Ah capacity for all strings connected in parallel.
5. Determine the Max. Batt. Recharge rate:  
Divide Total battery capacity by 20 hours and enter it in the appropriate box on the Site Form.
6. Verify that the Max. Batt. Recharge rate is set to the calculated value.
7. Remove ac power to the rectifiers purposely causing the battery discharge alarm to come on.
8. Verify that the System Current is  $0 \pm 5$  A.
9. Verify that the battery current is within 5 % of the system current recorded previously.
10. Restore ac power to the rectifiers.

### **Battery Temperature Test**

If the battery temperature probe is used in this system, verify that the battery temperature is correct.

### **LVD Test**

1. Ensure that the LVD parameters are set to proper values.
2. Record the LVD trip point.
3. To test the LVD function, set the LVD Trip to  $-56.00$  Vdc.
4. The LVD should have dropped out (opened). Verify it by monitoring the voltage at the battery connection.
5. Verify that the LVD Open Alarm is registered on the controller and at the customer remote alarm panel.
6. Reset the LVD Trip to the original setting.
7. Verify that the LVD Open Alarm has been removed.

## Battery Preventive Maintenance Procedure

The purpose of the preventive maintenance is to ensure that the battery is in good, working condition. The observations, measurements, and tests performed are designed to determine the “state of health” of the battery. It will also allow for the prediction of future performance and preempt possible failure.

1. Measure the float charge voltage.
  - a. At the power bay bus.
  - b. At the battery.
  - c. Reset voltage if necessary.
2. Measure the float current on each battery cable. If it is fluctuating, measure maximum and minimum.
3. Measure the ac ripple voltage at the battery.
4. Measure the float voltage of each cell or monoblock. Record the battery memory location allocated on the battery tester.
5. Perform a load test on each cell or monoblock and measure the internal cell resistance and inter-cell resistance of each cell or monoblock.
6. Ensure that all protective covers are replaced and that the battery is electrically non-hazardous to personnel that could be working in the vicinity

### 7.4. Final Inspection:

5. Verify that the interior and exterior of the system is clean and free from debris.
6. Ensure all wires connected and bolts are properly tightened.
7. Ensure the following the User, Service, and Calibration parameters are set properly on the controller (default settings are in parenthesis):

#### LVD

LVD1 Trip  
LVD1 Reset

#### Battery Parameters

Discharge Threshold  
Float Voltage  
Maximum Recharge  
Compensation Method

8. Verify on the status menu that the system is functioning correctly with no alarms.
9. Be sure to leave the site as orderly and neat as possible.

## 8 Alarm Summary

ALARM/ [MENU LOCATION]	DESCRIPTION	DEFAULT SETTINGS
Battery Discharge Alarm [Batteries/Parameters]	The battery discharge current exceeds the programmed battery discharge threshold.	Minor
Battery High Temp Alm [Batteries/Parameters]	The battery temperature exceeds the Battery High Temperature threshold.	Minor
Battery Low Temp Alm [Batteries/Parameters]	The Battery Temperature is below the battery Low Temperature threshold.	Minor
Battery LV Alm [Batteries/Parameters]	The dc output voltage is below the battery low voltage threshold.	Major
Circuit Breaker Alm 1 [Distribution/Breakers]	The top Circuit Breaker in the top shelf is tripped.	Major
Circuit Breaker Alm 2 [Distribution/Breakers]	The bottom Circuit Breaker in the top shelf is tripped	Major
Circuit Breaker Alm 3 [Distribution/Breakers]	The top Circuit Breaker in the bottom shelf is tripped.	Major
Circuit Breaker Alm 4 [Distribution/Breakers]	The bottom Circuit Breaker in the bottom shelf is tripped	Major
FUSE Alm 1 [Distribution/Fuses]	Any of Fuse 1 through 4 is blown.	Major
FUSE Alm 2 [Distribution/Fuses]	Any of Fuse 5 through 8 is blown.	Major
FUSE Alm 3 [Distribution/Fuses]	Any of Fuse 9 through 12 is blown.	Major
FUSE Alm 4 [Distribution/Fuses]	Any of Fuse 13 through 16 is blown.	Major
Hardware Batt Temp Alm [Batteries Parameters]	There is a hardware failure in the battery temperature monitoring function.	Minor
Hardware Sys Volt Alm [Power Modules/Rectifiers]	There is a hardware failure in the system voltage monitoring function.	Minor
Hardware Sys Temp Alm [System/DC Parameters]	There is a hardware failure in the system temperature monitoring function.	Minor.
System HT Alm [System/DC Parameters]	The System Temperature exceeds the system high temperature threshold. Not the same as battery temperature alarm.	Minor
System HV Alm [Power Modules/Rectifiers]	The System Voltage is above the System High Voltage threshold. Not the same as battery high voltage alarm.	Minor
Input Relay 1 [I/O/Input]	An external contact closure at the Input Relay 1 connection.	Ignore
•	•	•
•	•	•
•	•	•
Input Relay 4 [I/O/Input]	An external contact opening at the Input Relay 4 connection.	Ignore



<b>ALARM/ [MENU LOCATION]</b>	<b>DESCRIPTION</b>	<b>DEFAULT SETTINGS</b>
System LT Alm <b>[System/DC Parameters]</b>	The System Temperature is below the System Low Temperature threshold. Not the same as battery temperature alarm.	Minor
Low Voltage Alarm <b>[Power Modules/Rectifiers]</b>	The System Voltage is below the System Low Voltage threshold. Not the same as battery voltage alarm.	Minor
LVD Alarm <b>[Batteries/LVD]</b>	The controller opened the LVD. If unit has a battery LVD, no power will be available to turn on any Output Relays.	Major
User Output Relay 1 Alarm <b>[I/O/Output]</b>	Output Relay 1 Alarm can be “mapped” to activate other output relays (“Ignore” activates no additional relays).	Ignore
Rectifier 1-of-N Alm <b>[Power Modules/Rectifiers]</b>	Rectifier Fail 1-of-N alarm occurs. This is a special rectifier alarm group that signifies that one rectifier has at least one alarm condition.	Minor
Rectifier 2-of-N Alm <b>[Power Modules/Rectifiers]</b>	Rectifier Fail 2-of-N alarm occurs This is a special rectifier alarm group that signifies that more than one rectifier has at least one alarm condition.	Major
Rectifier Current Limit Alarm <b>[Power Modules/Rectifiers]</b>	A rectifier is in the current limited mode.	n of N
Rectifier Fan Fail Alm <b>[Power Modules/Rectifiers]</b>	A rectifier fan has failed.	n of N
Rectifier RFA Alarm <b>[Power Modules/Rectifiers]</b>	A rectifier output has failed.	n of N

## 9 Specifications

The overall system specifications can vary, depending upon the number of rectifier modules. Note that some specification items are provided on a “per rectifier” basis and must be combined or totaled for a given system configuration.

### 9.1. AC Input

#### TWF0500H54B Rectifier

Input Voltage Range	85 – 264 Vac
AC Frequency Range	47 – 63 Hz
Apparent Power Factor	99% Typical, 98% Minimum
Input Current (per Rectifier)	5.5 A @ 115Vac 3.7 A @ 230Vac
Turn on Time	2 Seconds

#### Magnum VS 50 Power System

Input Voltage Range	85 – 264 Vac
AC Frequency Range	47 – 63 Hz
Apparent Power Factor	99% Typical, 98% Minimum
Input Current	27.5 A @ 115 Vac 18.5 A @ 230 Vac

## Magnum VS 100 Power System

Input Voltage Range	85 – 264 Vac
AC Frequency Range	47 – 63 Hz
Apparent Power Factor	99% Typical, 98% Minimum
Input Current	55 A @ 115 Vac 37 A @ 230 Vac

## 9.2. DC Output

### TWF0500H54B Rectifier

Output Voltage (factory set)	54.5 Vdc
Operating Voltage Range	44 – 58 Vdc
Efficiency	85% Typical
Over Voltage Protection	59.5 Vdc
Output Current per Rectifier	9.0 A Minimum Continuous at 115 Vac Input 10.5 A Minimum Continuous at 230 Vac Input.
Current Limit	9.3 A Maximum at 115 Vac Input 11.0 A Maximum at 230 Vac Input.
Power Output per Rectifier @ 54.5Vdc	490 W Continuous at 115 Vac Input 570 W Continuous at 230 Vac Input

### Magnum VS 50 Power System

Output Voltage (factory programmed)	54.0 Vdc
Operating Voltage Range	47 – 56.5 Vdc
Rated Output Current	50 A
Efficiency	85% Typical
Over Voltage Protection	59.5 Vdc
Output Current	45 A Minimum Continuous at 115 Vac Input 52.5 A Minimum Continuous at 230 Vac Input.
Current Limit	46.5 A Maximum at 115 Vac Input 55.0 A Maximum at 230 Vac Input.
Power Output @ 54.5 Vdc	2450 W Continuous at 115 Vac Input 2850 W Continuous at 230 Vac Input

### Magnum VS 100 Power System

Output Voltage (factory programmed)	54.0 Vdc
Operating Voltage Range	47 – 56.5 Vdc
Rated Output Current	100 A
Efficiency	91% Typical
Over Voltage Protection	59.5 Vdc
Output Current	90 A Minimum Continuous at 115 Vac Input 105 A Minimum Continuous at 230 Vac Input.
Current Limit	93 A Maximum at 115 Vac Input 110 A Maximum at 230 Vac Input.
Power Output per Rectifier @ 54.5Vdc	4900 W Continuous at 115 Vac Input 5700 W Continuous at 230 Vac Input

## 9.3. Controls and Indicators

### TWF0500H54B Rectifier

Input Healthy LED	AC power present.
Output Healthy LED	DC output voltage between 39.5 to 59.5 Vdc.
Current Limit LED	On when rectifier is in current limit.
Overvolts LED	On when rectifier is above 57 Vdc. (Must be powered down to reset)

### Magnum VS Controller

DC OK (Green)	On when voltage is between 50 and 57 Vdc.
Major (Red)	On when Major Relay is de-energized*
Minor (Yellow)	On when Minor Relay is energized
Out Relay 1 (Red)	On when Output Relay 1 is energized
(Flashing Green)	Watchdog LED

\* Major relay is energized in normal operation. If all power fails, major relay will lose power and the contacts will change state, signifying an alarm.

## 9.4. Mechanical

### TWF0500H54B Rectifier

Dimensions (Overall)	5 in (12.7 cm) high x 2.75 in (7 cm) wide x 10.5 in (26.7 cm) deep
Dimensions (not including faceplate or connectors)	5 in (12.7 cm) high x 2.5 in (6.3 cm) wide x 9.4 in (24 cm) deep
Weight	4 lb (1.8 kg)
Color	Black front, Yellow zinc sides and back
Mounting	Hot swappable. Secured with 2.5 mm captive screws

### Magnum VS 50 Power System

Dimensions	5-1/4 in (13.3 cm) high x 17-1/4 in (43.8 cm) wide x 13 in (33cm) deep
Weight	15 lb. (6.8 kg)
Color	Black Front, Yellow zinc sides and back
Mounting	19" Rack Mounting (23" Optional)

### **Magnum VS 100 Power System**

Dimensions	10-1/2 in (26.6 cm) high x 17-1/4 in (43.8 cm) wide x 13 in (33cm) deep
Weight	30 lb. (13.6 kg)
Color	Black Front, Yellow zinc sides and back
Mounting	19" Rack Mounting (23" Optional)

## **9.5. Environmental**

Ambient Temperature	(Operating)	-40°C to +55°C (+65°C with reduced power output)
	(Storage)	-45°C to +85°C
Humidity	(Operating)	0 – 85% RH (non-condensing)
	(Storage)	0 – 95% RH (non-condensing)
Altitude	(Operating)	3000 m (9840 ft.)
	(Storage)	10000 m (39370 ft.)

## 9.6. Compliance

NEBS	Level 3 (Pending)
Safety	UL 60950 CE Marked to Low Voltage Directive (EN60950)
EMC	FCC Part 15 Class A EN55022 Class A, EN55024 EN61000-3-2, EN61000-3-3

## 10 *APC Worldwide Customer Support*

---

Customer Support for this or any other APC product is available at no charge. You can contact APC Customer Support in any of the following ways:

- Use an APC web page to find answers to frequently asked questions (FAQs), to access documents in the APC Knowledge Base, and to submit customer support requests.
  - <http://www.apc.com>  
Connect by links to APC web pages for specific countries and regions, each of which provides customer support information.
  - <http://www.apc.com/support/>  
Submit customer support requests.
  - <http://www.apc.com/support/contact>  
For e-mail addresses and local, country-specific, customer support telephone numbers worldwide.
- Contact Local or regional APC Customer Support by telephone.

<b>US and Canada</b>	1-(800) 800-4272	<b>Netherlands</b>	0800 0232509
<b>China</b>	800 810 0160	<b>Norway</b>	800 10436
<b>Austria</b>	0800 999670	<b>Poland</b>	0801 345917
<b>Belgium</b>	0800 40677	<b>Portugal</b>	800 853182
<b>Czech Republic</b>	800 102063	<b>Russia</b>	8800 2002722
<b>Denmark</b>	80 884953	<b>Slovak Republic</b>	0800 172063
<b>Finland</b>	0800 115308	<b>South Africa</b>	086 1 272877
<b>France</b>	0805 110053	<b>Spain</b>	800 853182
<b>Greece</b>	00800 125924	<b>Sweden</b>	0200 895283
<b>Hungary</b>	0640 200262	<b>Switzerland</b>	0800 111469
<b>Ireland</b>	1890 272877	<b>Turkey</b>	800 2612135
<b>Israel</b>	1800 9452206	<b>United Kingdom</b>	0800 2799254
<b>Italy</b>	800 22091	<b>Ukraine</b>	8800 5027220
<b>Luxembourg</b>	800 22091	<b>Worldwide</b>	(+1) 1 401 789-5735

- Contact the APC representative or other distributor from whom you purchased your APC hardware device or APC software application for information on how to obtain local customer support.



## 11 *Limited Product Warranty*

---

The limited warranty provided by American Power Conversion Corporation ("APC") in this Statement of Limited Factory Warranty applies only to Products Buyer purchases for your commercial or industrial use in the ordinary course of Buyer's business.

### **APC PRODUCTS COVERED ("Product or Products"):**

Magnum VS 50  
Magnum VS 100

### **Terms of Warranty:**

APC warrants that the Product shall be free from defects in materials and workmanship, for a period of two (2) years from the date of shipment.

### **Warranty Procedure**

If initial physical inspection results in identification of a material or workmanship flaw(s) that could impair Product performance as defined by APC's electrical and physical specification in effect at the time of shipment, and if this flaw(s) is not due to transportation damage or installation abuse, contact APC or call the 24-hour emergency number, (800) 800 4APC, to request assistance.

You will be provided either a) an RMA number with instructions for return of the equipment or component(s) to the APC factory service center, FOB destination, freight pre-paid, for examination, or b) for non-returnable systems and equipment, notice to wait until an APC authorized service representative arrives at the site to inspect the equipment. Repaired or advance replacement modules or circuit components will normally be available within 24 to 48 hours of receipt of equipment or RMA.

### **Warranty Obligations - Repair or Replacement**

If, during the warranty period, the Product is found to be physically or electrically faulty due to defective materials or workmanship, the defective Product(s) or component(s) will be repaired or replaced at the sole option of APC. If the procedure outlined above for contacting APC immediately after identifying a material or workmanship flaw(s) that could impair Product performance has been properly followed, such repair or replacement of Product(s) or component(s) shall include all charges for replacement materials or repair labor. Costs incurred for replacement installation including, but not limited to, installation equipment, travel expenses of an APC representative(s), and costs of installation material transportation expenses are not included as a part of this warranty. Any replacement components or materials furnished under this warranty may be new or factory remanufactured. THIS WARRANTY DOES NOT COVER CONSUMABLES OR PREVENTATIVE MAINTENANCE ITEMS. REPAIR OR REPLACEMENT OF A DEFECTIVE PRODUCT OR COMPONENT THEREOF DOES NOT EXTEND THE ORIGINAL WARRANTY PERIOD.

### **Exclusions and Limitations**

This Warranty is extended to the first person, firm, association or corporation for whom the APC Product specified herein has been bought. This Warranty is not transferable or assignable without the prior written permission of APC.

This limited warranty does not cover damage due to external causes, including accident, abuse, misuse, servicing not authorized by APC, usage not in accordance with Product instructions, failure to perform preventative maintenance, and problems caused by use of parts and components not supplied by APC. This limited warranty does not apply to Products from which the serial numbers have been removed, or to conditions resulting from improper use, accidents, external causes, including installation, relocation of hardware, service or modifications not performed by APC or its authorized service providers, or operation outside the environmental parameters specified for the Product. APC does not warrant that the operation of any Product will be uninterrupted or error free. Warranty service may not be performed if APC or other suppliers reasonably believe conditions at the Buyer's site represent a safety or health risk.

THERE ARE NO WARRANTIES, EXPRESS OR IMPLIED, BY OPERATION OF LAW OR OTHERWISE, OF PRODUCTS SOLD, SERVICED OR FURNISHED UNDER THIS AGREEMENT OR IN CONNECTION HERewith. APC DISCLAIMS ALL IMPLIED WARRANTIES OF MERCHANTABILITY, SATISFACTION AND FITNESS FOR A PARTICULAR PURPOSE. APC'S EXPRESS WARRANTIES WILL NOT BE ENLARGED, DIMINISHED, OR AFFECTED BY AND NO OBLIGATION OR LIABILITY WILL ARISE OUT OF, APC'S RENDERING OF TECHNICAL OR OTHER ADVICE OR SERVICE IN CONNECTION WITH THE PRODUCTS. THE FOREGOING WARRANTIES AND REMEDIES ARE EXCLUSIVE AND IN LIEU OF ALL OTHER WARRANTIES AND REMEDIES. THE WARRANTIES SET FORTH ABOVE, CONSTITUTE APC'S SOLE LIABILITY AND YOUR EXCLUSIVE REMEDY FOR ANY BREACH OF SUCH WARRANTIES. APC'S WARRANTIES RUN ONLY TO YOU AND ARE NOT EXTENDED TO ANY THIRD PARTIES. IN NO EVENT SHALL APC, ITS OFFICERS, DIRECTORS, AFFILIATES OR EMPLOYEES BE LIABLE FOR ANY FORM OF INDIRECT, SPECIAL, CONSEQUENTIAL OR PUNITIVE DAMAGES, ARISING OUT OF THE USE, SERVICE OR INSTALLATION, OF THE PRODUCTS, WHETHER SUCH DAMAGES ARISE IN CONTRACT OR TORT, IRRESPECTIVE OF FAULT, NEGLIGENCE OR STRICT LIABILITY OR WHETHER APC HAS BEEN ADVISED IN ADVANCE OF THE POSSIBILITY OF SUCH DAMAGES.